


# CMX34BT cpuModules™



## User's Manual

BDM-61000086 Revision B



[www.rtd.com](http://www.rtd.com)

ISO9001 and AS9100 Certified

**rttd**<sup>®</sup>  
"Accessing the Analog World"

## **CMX34BT *cpuModules*™ User's Manual**

RTD Document Number: BDM-610000086 Revision B

Copyright © 2009-2018 RTD Embedded Technologies, Inc. All rights reserved.

### **Trademarks**

Advanced Analog I/O, Advanced Digital I/O, aAIO, aDIO, a2DIO, Autonomous SmartCal, "Catch the Express", *cpuModule*, *dspFramework*, *dspModule*, *expressMate*, *ExpressPlatform*, *HiDANplus*, "MIL Value for COTS prices", *multiPort*, *PlatformBus*, and *PC/104EZ* are trademarks, and "Accessing the Analog World", *dataModule*, *IDAN*, *HiDAN*, *RTD*, and the RTD logo are registered trademarks of RTD Embedded Technologies, Inc (formerly Real Time Devices, Inc.). *PS/2* is a trademark of International Business Machines Inc. *PCI*, *PCI Express*, and *PCIe* are trademarks of PCI-SIG. *PC/104*, *PC/104-Plus*, *PCI-104*, *PCIe/104*, *PCI/104-Express* and *104* are trademarks of the *PC/104 Embedded Consortium*. All other trademarks appearing in this document are the property of their respective owners.

Failure to follow the instructions found in this manual may result in damage to the product described in this manual, or other components of the system. The procedure set forth in this manual shall only be performed by persons qualified to service electronic equipment. Contents and specifications within this manual are given without warranty, and are subject to change without notice. RTD Embedded Technologies, Inc. shall not be liable for errors or omissions in this manual, or for any loss, damage, or injury in connection with the use of this manual.

# CMX34BT cpuModules™

[www.rtd.com](http://www.rtd.com)



ISO9001 and AS9100 Certified



## Revision History

Revision	Date	Reason for Change
A	07/28/2017	Initial release
B	01/03/2018	Throughout: Correct designator shown in labels for COM2&4 Throughout: Update trademark for “Intel Atom®” Intro: Add ordering part numbers for boards which include flat-heatspreaders Connecting: Correct number of PCIe links shown in “PCIe Link Configuration” Appendix A: Update 3D dimensional drawings for the passive heatsinks to show PCB Appendix A: Add 3D dimensional drawings for the flat-heatspreaders

# Table of Contents

## Chapter 1 Introduction

<b>CMX34BT cpuModules</b> .....	2
aDIO .....	3
<b>Ordering Information</b> .....	4
CMX34BT Model Options .....	4
Cable Kits and Accessories .....	4
<b>Board Features</b> .....	5
I/O .....	7
RTD Enhanced BIOS .....	9
<b>Block Diagram</b> .....	10
<b>Specifications</b> .....	11
Physical Characteristics .....	11
Power Consumption .....	11
Operating Conditions .....	12
Electrical Characteristics .....	13
<b>Migrating to RTD's Intel E3800 Series cpuModules</b> .....	15
Connector Pinout & Function Differences .....	15
New I/O Connectors .....	15
Connector Differences .....	15
Software Differences .....	17
aDIO .....	17
UEFI Shell .....	17
<b>Contact Information</b> .....	18

## Chapter 2 Getting Started

<b>Connector Locations</b> .....	20
<b>Selecting the Stack Order for the CMX34BT</b> .....	22
<b>Stack Example</b> .....	23
<b>Connecting to the Stack</b> .....	24
<b>Power Input Connections</b> .....	24
<b>Connecting to the Utility Port 2.0 Connector</b> .....	25
<b>Booting the CMX34BT cpuModule for the First Time</b> .....	25

## Chapter 3 Connecting the cpuModule

<b>Proper Grounding Techniques</b> .....	28
<b>Connector Locations</b> .....	28
<b>Auxiliary Power (CN3)</b> .....	30
<b>Utility Port 2.0 Connector (CN5)</b> .....	31
USB 2.0 Connector .....	32

Speaker .....	32
System Reset .....	32
Soft Power Button .....	32
Battery .....	33
<b>SVGA Video Connector (CN18) .....</b>	<b>34</b>
<b>DisplayPort Connector (CN19).....</b>	<b>35</b>
<b>Serial Port 1 (CN7) and Serial Port 2 (CN8) .....</b>	<b>37</b>
Serial Port UART .....	37
RS-232 Serial Port (Default) .....	37
RS-422 or RS-485 Serial Port .....	38
RS-422 Mode Pinout .....	39
RS-485 Mode Pinout .....	40
Dual Serial Port Modes.....	41
<b>Advanced Digital I/O (aDIO™) Port (CN6).....</b>	<b>43</b>
<b>USB 2.0 Connectors (CN17 and CN27) .....</b>	<b>44</b>
<b>Ethernet (10/100/1000Base-T and -TX) Connectors (CN20 and CN30) .....</b>	<b>46</b>
<b>PCIe/104 Type 2 Bus (CN1 - Top and CN2 - Bottom) .....</b>	<b>47</b>
PCIe/104 Type 2 Compatibility .....	49
PCIe Link Configuration.....	50
<b>Optional RTC Battery Input (CN13).....</b>	<b>51</b>
<b>Fan Power (CN15) .....</b>	<b>51</b>
<b>Chapter 4     Using the cpuModule</b>	
<b>The RTD Enhanced BIOS .....</b>	<b>54</b>
Configuring the RTD Enhanced BIOS .....	54
Entering the BIOS Setup through the Graphical BIOS Menu.....	54
Field Selection .....	55
<b>Operating System Specific Usage.....</b>	<b>56</b>
Windows® .....	56
Linux® .....	56
UEFI OS Installations.....	56
<b>Non-Standard Serial Port Modes .....</b>	<b>57</b>
<b>Advanced Digital I/O Ports (aDIO™).....</b>	<b>58</b>
Digital I/O Register Set .....	58
Port 1 Data register is a read/write byte direction .....	60
Interrupts .....	60
Advanced Digital Interrupts .....	60
Event Mode.....	60
Match Mode.....	60
Strobe Mode.....	61
<b>SATA Controller Configuration.....</b>	<b>62</b>
SATA Port Mappings, by Connector .....	62
Onboard SATA Storage .....	62
SATA Links on the PCIe/104 Type Connectors .....	62
Native IDE Mode.....	62

<b>Watchdog Timer Control</b> .....	63
<b>Thermal Management</b> .....	64
Thermal Warning .....	64
ACPI-Enforced Thermal Protection .....	64
Critical Trip Point .....	64
Passive Trip Point .....	64
<b>Power Management</b> .....	65
Advanced Configuration and Power Interface (ACPI) .....	65
Power Button Modes .....	65
Low-Power Wake Options .....	65
AT vs. ATX Power Supplies .....	66
ATX Power Supply Signals .....	66
Reducing Power Consumption .....	66
<b>Multi-Color LED</b> .....	67
<b>Reset and Event Status Register</b> .....	68
<b>Features and Settings That Can Affect Boot Time</b> .....	70
Boot Device Order .....	70
Add-On Cards With BIOS Extensions .....	70
VGA Controller .....	70
Hard Drive Type .....	70
Monitor Type .....	70
<b>System Recovery</b> .....	71
Reset Button Recovery .....	71
Load Default BIOS Settings .....	71
Serial Power-On-Self-Test (POST) Code Output .....	71
<b>Appendix A Hardware Reference</b>	
<b>Jumper Settings and Locations</b> .....	74
<b>Onboard PCI/PCIe Devices</b> .....	75
<b>Physical Dimensions</b> .....	76
<b>Heatsink Dimensions</b> .....	77
<b>Flat-Heatspreader Dimensions</b> .....	79
<b>Appendix B Troubleshooting</b>	
<b>Common Problems and Solutions</b> .....	82
<b>Troubleshooting a PC/104 System</b> .....	83
<b>How to Obtain Technical Support</b> .....	84
<b>Appendix C IDAN™ Dimensions and Pinout</b>	
<b>IDAN Contents</b> .....	86
<b>IDAN Dimensions</b> .....	86
<b>IDAN Connector Locations</b> .....	87

**External I/O Connections** ..... 89

**Appendix D Additional Information**

**Application Notes** ..... 95

**Drivers and Example Programs**..... 95

**Interrupt Programming** ..... 95

**Serial Port Programming** ..... 95

**PC/104 Specifications** ..... 95

**Appendix E Limited Warranty**



# Chapter 1 Introduction

This manual provides comprehensive hardware and software information for users developing with the CMX34BT PCIe/104 cpuModule.



**Note** Read the specifications beginning on page 11 prior to designing with the cpuModule.

This manual is organized as follows:

- Chapter 1**     **Introduction**  
introduces main features and specifications
- Chapter 2**     **Getting Started**  
provides abbreviated instructions to get started quickly
- Chapter 3**     **Connecting the cpuModule**  
provides information on connecting the cpuModule to peripherals
- Chapter 4**     **Using the cpuModule**  
provides information to develop applications for the cpuModule, including general cpuModule information, detailed information on storing both applications and system functions, and using utility programs
- Appendix A**   **Hardware Reference**  
lists jumper locations and settings, physical dimensions, and processor thermal management
- Appendix B**   **Troubleshooting**  
offers advice on debugging problems with your system
- Appendix C**   **IDAN™ Dimensions and Pinout**  
provides connector pinouts for the cpuModule installed in an RTD Intelligent Data Acquisition Node (IDAN) frame
- Appendix D**   **Additional Information**  
lists sources and websites to support the cpuModule installation and configuration
- Appendix E**   **Limited Warranty**

## CMX34BT cpuModules

RTD's CMX34BT cpuModule represents the latest in low power PCI Express embedded controllers. Based on an Intel Atom® E3800 Series processor and chipset, the CMX34BT is offered with either a low power 1.46 Ghz Single-Core processor, a 1.33GHz Dual-Core processor, or a 1.91 GHz Quad-Core processor. The DDR3 memory interface on the single- and dual-core models operate up to 1066 MT/s (533 MHz) while the quad-core is 1333-MT/s (666 MHz). All memory chips are soldered directly onto the board.

The video interface of the cpuModule's Intel Atom's processor supports dual analog SVGA and DisplayPort outputs. The two video outputs are independent, and can display separate images and display timings, with audio support on the DisplayPort. Maximum resolution of both video outputs is 1920 x 1200.

A Serial-ATA (SATA) controller provides links to one disk drive on the PCIe bus connector as well as an onboard solid-state disk drive which is soldered to the board for maximum reliability. Network connectivity is provided by one integrated 10/100/1000 Mbps Ethernet controller. High-speed peripheral connections include USB 2.0, with up to 480 Mb/sec data throughput. One additional SATA link and four USB 2.0 connections permit further expandability on the top and bottom-side PCIe/104 Type 2 connectors. The bottom PCIe/104 connector also has x1 PCI Express Gen 2.0 links. Other features include RS-232/422/485 COM ports and Advanced Digital I/O (aDIO).

RTD has gone the extra mile to include additional advanced features for maximum flexibility. These include an onboard surface-mount flash drive with a standard SATA interface. An Advanced Watchdog Timer is provided that can generate an interrupt or reset when the timer expires. The CMX34BT is also available in a rugged and fanless IDAN enclosure.




Figure 1 CMX34BT cpuModule (top view)

You can easily customize the cpuModule by stacking PCI/104-Express or PCIe/104 modules such as video controllers, Digital Signal Processors, drive carriers, LAN controllers, or analog and digital data acquisition modules. Stacking modules onto the cpuModule avoids expensive installations of backplanes and card cages, and preserves the module's compactness.

The cpuModule uses the RTD Enhanced BIOS. Drivers in the BIOS allow booting from hard disk, or UEFI shell, thus enabling the system to be used with traditional disk drives or nonmechanical drives. Booting to USB devices is also supported.

The cpuModule and BIOS are compatible with any real-time operating systems for PC compatible computers, although these may require creation of custom drivers to use the aDIO and watchdog timer.

## **aDIO**

RTD's exclusive aDIO™ is 12 digital bits configured as 8 bit-direction programmable and 4-bit port-direction programmable I/O, plus 2 strobe inputs giving you any combination of inputs and outputs. Match, event, and strobe interrupt modes mean no more wasting valuable processor time polling digital inputs. Interrupts are generated when the 8 bit-direction programmable digital inputs match a pattern or on any value change event. Bit masking allows selecting any subgroup of eight bits. The strobe input latches data into the bit-programmable port and generates an interrupt.

## Ordering Information

The CMX34BT cpuModule is available with a selection of processors and heatsinks. The cpuModule can also be purchased as part of an Intelligent Data Acquisition Node (IDAN™) building block, which consists of the cpuModule and a milled aluminum IDAN frame. The IDAN building block can be used in just about any combination with other IDAN building blocks to create a simple but rugged PC/104 stack. Refer to Appendix C, *IDAN™ Dimensions and Pinout*, for more information. The CMX34BT cpuModule can also be purchased as part of a custom-built RTD HiDAN™ or HiDAN*plus* High Reliability Intelligent Data Acquisition Node. Contact RTD for more information on its high reliability PC/104 systems.

### CMX34BT Model Options

The basic cpuModule model options are shown below. Refer to the RTD website ([www.rtd.com](http://www.rtd.com)) for more detailed ordering information and any new variations that may be available.

**Table 1 CMX34BT cpuModule Model Options**

Part Number	Description	Stack Height
CMX34BTS1460HR-4096/S32GX	Intel Atom® E3815, Single Core 1.46 GHz 4GB DDR3-SDRAM	15.24mm
CMX34BTD1330HR-4096/S32GX	Intel Atom® E3825, Dual Core 1.33 GHz 4GB DDR3-SDRAM	15.24mm
CMX34BTQ1910HR-4096/S32GX	Intel Atom® E3845, Quad Core 1.91 GHz 4GB DDR3-SDRAM	22mm
CMX34BTS1460HR-4096/S32GXF	CMX34BTS1460HR-4096/S32GX with Flat Heatspreader	15.24mm
CMX34BTD1330HR-4096/S32GXF	CMX34BTD1330HR-4096/S32GX with Flat Heatspreader	15.24mm
CMX34BTQ1910HR-4096/S32GXF	CMX34BTQ1910HR-4096/S32GX with Flat Heatspreader	22mm

### Cable Kits and Accessories

For maximum flexibility, RTD does not provide cables with the cpuModule. You may wish to purchase the CMX34BT cpuModule cable kit (P/N), which contains:

- Utility Port 2.0 multi-function cable (2x USB 2.0 ports, battery, reset button, power button, speaker)
- Two serial port cables (DIL-10 to DSUB-9)
- VGA monitor cable (DIL-10 to high density 15-pin DSUB)
- aDIO cable (DIL-16 to DSUB-25)
- One USB cables (5-pin SIL to USB A)
- PCIe/104 Type 2 break-out board (provides standard PC interfaces for SATA and USB devices)
- One Ethernet cable (DIL-10 to RJ-45)

For additional accessories, refer to the RTD website.

## Board Features

- Intel Atom® E3800 Series Processor:

Part Number	Cores	Core Frequency	L1 Cache (data)	L1 Cache (instruction)	L2 Cache	Stack Height
CMX34BTS1460	One	1.46 GHz	32 KByte	32 KByte	512 KByte	0.600" (15.24mm)
CMX34BTD1330	Two	1.33 GHz	32 KByte <sup>1</sup>	32 KByte <sup>1</sup>	512 KByte <sup>1</sup>	0.600" (15.24mm)
CMX34BTQ1910	Four	1.91 GHz	32 KByte <sup>1</sup>	32 KByte <sup>1</sup>	512 KByte <sup>1</sup>	0.866" (22mm)

1. Discreet L1 and L2 cache structures for each core

- Intel Atom® technology
  - E3815 Single Core Processor
  - E3825 Dual Core Processor
  - E3845 Quad Core Processor
- ACPI 5.0 compliant
- Thermal Throttling reduces clock speed to prevent thermal runaway
- 22 nm process
- Max Core Temperature of 110 C
- 2-4 GBytes BGA DDR3 SDRAM
  - Single-channel memory interface
  - Transfer rates up to 1333 MT/s Data Rate
  - Surface Mounted for maximum reliability
- Stackable 156-pin PCIe/104 Type 2 bus on top
  - One SATA 2.0, Rev 2.0 3GB/s
  - Two USB 2.0
  - ATX Power Supply Signaling
  - RTC Battery
- Stackable 156-pin PCIe/104 Type 2 bus on bottom
  - Four PCI Express x1 Links. Gen 2, 5 GT/s
  - Two USB 2.0
  - ATX Power Supply Signaling
  - RTC Battery
- Advanced Thermal Management
  - Thermal Monitor throttles processor and memory to prevent thermal runaway
  - Passive Fanless Heatsink
  - Modified heatsinks and flat heat spreaders are available
  - Optional connector for external fan
  - Passive Structural Heatsink & Heatpipes in IDAN and HiDAN System Configurations
- Advanced Configuration and Power Interface (ACPI)
  - ACPI 5.0 Compliant
  - Wake events include:

- USB event (device insertion, keyboard keystroke, etc.)
- Power Switch
- etc.
- Real-Time Clock (external battery required to maintain time only)
- Nonvolatile storage of CMOS settings without battery
- Advanced Watchdog timer
- Complete PC-compatible Single Board Computer

## I/O

- Analog VGA Interface
  - RGB CRT output
  - Maximum Resolution 1920 x 1200
- DisplayPort Interface
  - Embedded DisplayPort (eDP) 1.3
  - DisplayPort, DVI, and HDMI
  - Audio over DisplayPort
- Gigabit Ethernet
  - Intel 82574IT Controllers (PRO1000 Series)
  - 10/100/1000 Auto-negotiation
  - Jumbo Frame Support (9kB)
  - Automatic MDI/MDI-X crossover capable
- Software-configurable RS-232/422/485 serial ports
  - 16550 compatible UARTs for high-speed
  - 120 Ohm Termination resistors for RS-422/485 through BIOS Configuration
  - Fully jumperless configuration
  - Increased FIFO size of 512 bytes
  - Supports echo cancellation, Auto-RTS and Auto-CTS
  - Each serial port can be configured as two limited serial ports for a total of four serial ports
- Advanced Digital I/O (aDIO)
  - One 8-bit bit-programmable I/O with Advanced Digital Interrupt Modes
  - One 4-bit port programmable as input or output
  - Event Mode Interrupt generates an interrupt when any input bit changes
  - Match Mode Interrupt generates an interrupt when input bits match a preset value
  - External Strobe Mode latches 8 data inputs and generates an interrupt
  - Two Strobes can be configured as readable inputs
- Two USB 2.0 (Universal Serial Bus) Ports
  - Supports 480 Mb/s (high-speed), 12Mb/s (full-speed), and 1.5Mbs (low speed) peripherals
  - Automatic resettable over-current protection (500 mA @ 5 Vdc per port)
  - USB Boot capability
  - Seven ports total (3 on 0.1" I/O headers, 4 on PCIe bus connectors)
- Serial ATA (SATA)
  - Two SATA revision 2.0 links
    - One link to the top-side PCIe connector
    - One link to the onboard surface-mount SATA Flash drive
  - Onboard 32 GB SATA Flash drive
    - Built in Wear Leveling, Error Correction and Bad Block Management
    - SMART supported (Self-Monitoring, Analysis and Reporting Technology)
  - Compatibility mode supports legacy operating systems.
- Utility Port 2.0 Connector

- 1x USB 2.0 (Universal Serial Bus) Port with over-current protection
  - Speaker port (0.1 W output)
  - Hardware Reset input
  - Soft Power Button input
- Battery input for Real Time Clock
- Power Management
  - ACPI 5.0 Support - Advanced Configuration and Power interface
  - ATX support for “Soft Off”
  - ATX Power signals




## **RTD Enhanced BIOS**

- User-configurable using built-in Setup program
- Flash-based CMOS Setup; no battery required to store CMOS settings
- Supports boot from SATA or USB
- UEFI (Unified Extensible Firmware Interface) Shell
- Special RTD Reliability Enhancements

# Block Diagram

The next figure shows a simplified block diagram of the CMX34BT cpuModule.



**Figure 2 CMX34BT cpuModule Simplified Block Diagram**

# Specifications

## Physical Characteristics

Basic dimensions and the weight of the CMX34BT are listed below. For a more detailed dimensional drawing, refer to the *Physical Dimensions* section on page 76.

- Dimensions
  - Board Size
    - Length (L): 95.885 mm L (3.775")
    - Width (W): 90.170 mm W (3.550")
  - Stand-off Height Above the CPU:
    - Single- and Dual-core models: 15.240 mm (0.866")
    - Quad-core models 22.000 mm (0.866")
  - Stand-off Height Below the CPU:
    - All versions: 15.240mm (0.600")
- Approximate Weight with Heatsink
  - Single-core models: 0.12 kg (0.26 lb)
  - Dual-core models: 0.16 kg (0.36 lb)
  - Quad-core models: 0.19 kg (0.42 lb)
- Approximate IDAN weight
  - All models: 0.64 kg (1.40 lb)

## Power Consumption

Exact power consumption depends on the actual application. Typical power consumption of the CMX34BT is listed in Table 2. It is expected that power consumption of a typical application will be a combination of these scenarios.

**Table 2 Typical Power Consumption**

Part Number	Typical Power Consumption
CMX34BTS615HR-4096	7.1 W
CMX34BTD1330HR-4096	7.6 W
CMX34BTQ1910HR-4096	9.5 W



**Note** The measurements listed above are intended to represent common usage scenarios. The *cpuModule's* power consumption is heavily influenced by the running software and system activity.

## Operating Conditions

**Table 3 Operating Conditions**

Symbol	Parameter	Test Condition	Min.	Max.
$V_{CC5}$	5V Supply Voltage		4.75V	5.25V
$V_{CCSTBY}$	5V Standby Voltage <sup>1</sup>		4.75V	5.25V
$I_{CCSTBY}$	5V Standby Current <sup>1</sup>		-	500mA
$T_a$	Ambient Operating Temperature <sup>2</sup>		-40	+85C
$T_s$	Storage Temperature		-40	+70C
$R_h$	Humidity	Non-Condensing	0	90%

1. 5V Standby is used to power the board when the main supply is turned off (power down modes S3-S5). It is not required for board operation.
2. With supplied heat sink solution. Depending on the CPU usage, performance may degrade as the ambient temperature approaches the maximum. Contact RTD Tech Support for more information.

**Table 4 Mean Time Before Failure (MTBF)**

Part Number	Test Condition	MTBF (hrs)
CMX34BTS1460HR-4096/S32GX	30 C	441,418
CMX34BTD1330HR-4096/S32GX	30 C	441,418
CMX34BTQ1910HR-4096/S32GX	30 C	441,418

## Electrical Characteristics

The table below lists the Electrical Characteristics of the CMX34BT. Operating outside of these parameters may cause permanent damage to the cpuModule.

**Table 5 Electrical Characteristics**

Symbol	Parameter	Test Condition	Min.	Max.
<b>USB Ports</b>				
I <sub>oc</sub>	Overcurrent Limit	Each port	0.5 A	5.0 A
<b>SVGA Port</b>				
V <sub>OH</sub>	Output Voltage High HSYNC, VSYNC	I <sub>OH</sub> = -8.0 mA	2.4 V	3.3 V
V <sub>OL</sub>	Output Voltage Low HSYNC, VSYNC	I <sub>OL</sub> = 8.0 mA	0.0 V	0.5 V
V <sub>OH</sub>	Output Voltage High DDC_*	I <sub>OH</sub> = -4.0 mA	2.4 V	3.3 V
V <sub>OL</sub>	Output Voltage Low DDC_*	I <sub>OL</sub> = 8.0 mA	0.0 V	0.4 V
V <sub>IH</sub>	Input Voltage High DDC_*	—	2.0 V	5.5 V
V <sub>IL</sub>	Input Voltage Low DDC_*	—	-0.3 V	0.8 V
I <sub>DDCvcc</sub>	Supply Current for DDC Electronics	—		500 mA
<b>DisplayPort</b>				
I <sub>vcc</sub>	Supply Current	—		500 mA
<b>Serial Ports - RS-232</b>				
V <sub>OH</sub>	Output Voltage High	R <sub>L</sub> = 3 k	5.0 V	7.0 V
V <sub>OL</sub>	Output Voltage Low	R <sub>L</sub> = 3 k	-7.0 V	-5.0 V
V <sub>IH</sub>	Input Voltage High	—	2.0 V	15 V
V <sub>IL</sub>	Input Voltage Low	—	-15 V	0.6 V
<b>Serial Ports - RS-422/485</b>				
V <sub>OD1</sub>	Differential Output	R <sub>L</sub> = 100 Ohm	2.0 V	
V <sub>OD2</sub>	Differential Output	R <sub>L</sub> = 54 Ohm	1.5 V	
V <sub>OC</sub>	Common Mode Output	R <sub>L</sub> = 54 or 100 Ohm		3.0 V
V <sub>TH</sub>	Differential Input Threshold		-200 mV	-50 mV
V <sub>I</sub>	Absolute Max Input Voltage		-18 V	18 V
<b>aDIO</b>				
V <sub>OH</sub>	Output Voltage High	I <sub>OH</sub> = -29 mA	2.4 V	3.3 V
V <sub>OL</sub>	Output Voltage Low	I <sub>OL</sub> = 17 mA	0.0 V	0.5 V
V <sub>IH</sub>	Input Voltage High	—	1.8 V	5.5 V
V <sub>IL</sub>	Input Voltage Low	—	-0.3 V	0.8 V
I <sub>ADIOvcc</sub>	Supply current	—		500 mA

**Table 5 Electrical Characteristics**

Symbol	Parameter	Test Condition	Min.	Max.
$T_{MIN}$	Update Interval	—	1ms	
<b>Utility Port 2.0 Connector (CN5)</b>				
$V_{RTC}$	Input RTC Voltage <sup>1</sup>	—	2.3 V	3.6 V
$I_{RTC}$	RTC Battery Current	—		< 4 $\mu$ A
$I_{UTILVCC}$	Utility Supply Current	—		500 mA
<b>Optional Fan Connector (CN15)</b>				
$I_{FAN}$	Input Current to Fan	—		200 mA

1. Only required to maintain date and time when power is completely removed from the system. Not required for board operation.

# Migrating to RTD's Intel E3800 Series cpuModules

When migrating to RTD's Intel E3800 Series cpuModules, there are several differences from some preceding RTD cpuModule product families of which the customer should be aware.

## Connector Pinout & Function Differences

The Intel E3800 Series cpuModules have several connector-related differences, which are summarized below. Complete information about the connectors on the CMX34BT can be found in Chapter 3, *Connecting the cpuModule*.

### New I/O Connectors

The CMX34BT cpuModule introduces a new I/O connector that was not present on some previous RTD cpuModules:

- **DisplayPort (CN19)**
  - Provides video and audio output
  - Unlike legacy LVDS and flat panel connectors which needed to have their BIOS pre-configured to a specific manufacturer's flat panel parameters, the DisplayPort connector is compatible with any display that has a DisplayPort interface.

### Connector Differences

While some connectors on the CMX34BT have identical pinouts as on previous cpuModule generations, the features of the connector are sometimes different. Other connectors have entirely different pinouts than those on previous cpuModule generations. Connectors with pinout and feature differences include:

- **Auxiliary Power Connector (CN3)**
  - 12 pins (unlike the 10-pin connector on RTD Montevina cpuModules)
  - +5V and +12V inputs (unlike +5V only auxiliary power connectors found on previous RTD cpuModule generations)
    - While the RTD Intel E3800 Series CPU only requires +5 volts, +12V may optionally be connected to CN3 if it is required by any other device in the system.
  - The Auxiliary Power Connector excludes ATX power signaling. The ATX power signals are provided on the PCIe/104 Type 2 bus connectors.
- **Utility Port 2.0 (CN5)**
  - Replaces the legacy Utility Port multi-function connector
  - Replaces the PS/2 Mouse and Keyboard connections with one USB 2.0 port
  - The pinout of the Utility Port 2.0 is **not** compatible with previous generations of RTD cpuModules.
- **COM Ports (CN7 and CN8)**
  - Connector **CN7** can be configured to output Serial POST codes out of the TXD pin when in single RS-232 mode (unlike RTD Montevina cpuModules, where the DTR pin was configured for serial POST code output on the second port of CN7 in dual-port mode). For more information, refer to *Serial Power-On-Self-Test (POST) Code Output* on page 71.
  - Of all single and dual-port modes, only the single RS-232 pinout is compatible with previous generations of RTD cpuModules.
  - Dual-mode COM port pinouts permit dual RS-232, dual RS-422, and dual RS-485 modes. Unlike some previous generations of RTD cpuModules, a dual "combined" mode with RS-232 and RS-422/458 is not supported.

- Unlike some previous *cpuModule* generations, the single-mode RS-422/485 pinouts of the CMX34BT do not include the DCD, DSR, DTR, and RI signals.
- When a COM port connector is configured for dual-port mode, enabling/disabling COM port termination enables/disables the termination for both ports on that connector. (Some previous generations of *cpuModules* have the ability to independently enable/disable termination on both ports when configured for dual-mode.)



## Software Differences

The Intel E3800 Series cpuModules have several software-related differences, which are summarized below. Complete information about these CMX34BT features can be found in Chapter 4, *Using the cpuModule*.

### aDIO

While the 16-pin aDIO connector is pin-for-pin compatible with previous generations of RTD cpuModules (such as the Intel Core 2 Duo series), the hardware is slightly different, and requires that writes and reads to/from the aDIO ports happen no more than once per millisecond. Migrating legacy software to the E3800 Series that utilizes RTD's Advanced Digital I/O may require that you add this delay prior to all reads and writes.

### UEFI Shell

Previous generations of RTD cpuModules contained a Failsafe Boot ROM image, which permitted the cpuModule to boot to a DOS prompt even when no disk drives were connected to the system. The RTD E3800 Series cpuModules provide a similar prompt, called the Unified Extensible Firmware Interface (UEFI) Shell, which provides an environment to execute simple commands when no bootable devices are connected to the system.

## Contact Information

RTD Embedded Technologies, Inc.  
103 Innovation Blvd.  
State College, PA 16803-0906  
USA

**Phone:** +1-814-234-8087

**Fax:** +1-814-234-5218

**E-mail:** sales@rtd.com  
techsupport@rtd.com

**Internet:** <http://www.rtd.com>



## Chapter 2 Getting Started

For many users, the factory configuration of the CMX34BT cpuModule can be used to get a PC/104 system operational. You can get your system up and running quickly by following the simple steps described in this chapter, which are:

1. Before connecting the cpuModule, the user must be properly grounded to prevent electrostatic discharge (ESD). For more information, refer to *Proper Grounding Techniques* on page 28.
2. Connect power.
3. Connect the Utility Port 2.0 cable.
4. Connect a USB keyboard.
5. Connect a monitor to the SVGA connector or DisplayPort interface.
6. Default BIOS configuration.
7. UEFI (Unified Extensible Firmware Interface) shell.

Refer to the remainder of this chapter for details on each of these steps.

## Connector Locations

Figure 3 shows the connectors of the CMX34BT cpuModule.




Figure 3 CMX34BT Connector Locations



**Note** Pin 1 of each connector is indicated by a white silk-screened square on the top side of the board and a square solder pad on the bottom side of the board.

**Table 6 CMX34BT Basic Connectors**

Connector	Function	Size and Pitch	Mating Connector
<b>CN1</b>	PCIe/104 Type 2 Bus (Top)	156-pin, 0.635mm	Samtec ASP-129646-03
<b>CN2</b>	PCIe/104 Type 2 Bus (Bottom)	156-pin, 0.635mm	Samtec ASP-129637-03
<b>CN3</b>	Auxiliary Power	1x12, 0.1"	FCI 65039-025LF
<b>CN5</b>	Utility Port 2.0	2x5, 0.1"	3M 89110-0001
<b>CN6</b>	aDIO	2x8, 0.1"	3M 89116-0001
<b>CN7</b>	Serial Port 1 (COM 1&3)	2x5, 0.1"	3M 89110-0001
<b>CN8</b>	Serial Port 2 (COM 2&4)	2x5, 0.1"	3M 89110-0001
<b>CN13</b>	RTC Battery Input (optional)	1x2, 2mm	FCI 69305-002LF
<b>CN15</b>	Optional Fan Connector	1x3, 2mm	FCI 69305-003LF
<b>CN17</b>	USB 2.0	2x5, 0.1"	3M 89110-0001
<b>CN18</b>	Video (SVGA)	2x5, 0.1"	3M 89110-0001
<b>CN19</b>	DisplayPort	Molex P/N Series 47272-xxxx	Molex P/N Series 68783-xxxx
<b>CN20</b>	Ethernet	2x5, 0.1"	3M 89110-0001
<b>CN27</b>	USB 2.0	2x5, 0.1"	3M 89110-0001
<b>CN30</b>	Ethernet	2x5, 0.1"	3M 89110-0001



**WARNING** *If you connect power incorrectly, the module will almost certainly be damaged or destroyed. Such damage is not covered by the RTD warranty! Please verify connections to the module before applying power.*

Power is normally supplied to the cpuModule through the top or bottom PCIe connectors (**CN1** or **CN2**). If you are placing the cpuModule onto a stack that has a PCIe/104 power supply, you do not need to make additional connections to supply power.

Alternatively, if you are using the cpuModule without a PC/104 stack or with a stack that does not include a power supply, refer to *Auxiliary Power* (CN3) on page 30 for an alternative method on how to power the cpuModule.


## Selecting the Stack Order for the CMX34BT

There are several things to consider when selecting the order of boards in the stack. Before selecting the order, be sure to determine which bus connector on each board is the “Active” bus. Typically, if a peripheral module has both PCIe and PCI bus connectors, only the PCIe is active and the PCI is pass-through. The following is a list of rules to use to determine the stack order:

1. The PCIe connectors above and below the CPU have completely separate signals. Therefore it is possible to attach boards to the PCIe connector above and below the CPU.
2. Any board that uses a SATA link must be within one board of the CPU.
3. Any board that uses a PCIe link must be within six boards of the CPU. Peripheral boards that repopulate a PCIe link should be placed closer to the CPU than any peripheral boards that use a PCIe link without repopulating.
4. To preserve power integrity, it is recommended that there be no more than six boards between the CPU and the power supply.
5. In order to maintain maximum performance over the full temperature range, it is recommended that a PCIe spacer be used between the CPU and any board immediately above it.
6. A maximum of four PCI boards may be attached to any PCI bus.
7. The PCIe to PCI bridge (if one exists in the stack) must be at one end of the PCI bus segment, and all of the peripheral cards at the other end. There may be up to eight PCI pass-through connectors between the PCIe to PCI bridge and the peripheral cards.
8. There must be no more than two boards between the first PCI peripheral and the last PCI peripheral. If there are four PCI peripheral cards in a PCI bus segment, there may not be any PCI pass-through connections between them.

## Stack Example

The figure below shows an example of a complete system stack. Most systems will be a subset of this example. This example stack may be further expanded with PCIe to PCIe bridges, or a PCIe to PCI bridge.



**Figure 4 System Stacking Example**

## Connecting to the Stack

The bus connectors of the cpuModule are simply plugged onto a PC/104 stack to connect to other devices. Follow the procedure below to ensure that stacking of the modules does not damage connectors or electronics.



**WARNING** Do not force the module onto the stack! Wiggling the module or applying too much pressure may damage it. If the module does not readily press into place, remove it, check for bent pins or out-of-place keying pins, and try again.

---

For mechanical dimensions, including board-to-board spacing, see *Physical Dimensions* on page 76.

1. Turn off power to the PC/104 system or stack.
2. Always work at an ESD protected workstation, and wear a grounded wrist-strap.
3. Select and install stand-offs to properly position the cpuModule on the stack.
4. Remove the cpuModule from its anti-static bag.
5. Check that pins of the bus connector are properly positioned.
6. Check the stacking order; make sure all of the busses used by the peripheral cards are connected to the cpuModule.
7. Hold the cpuModule by its edges and orient it so the bus connector pins line up with the matching connector on the stack.
8. Gently and evenly press the cpuModule onto the PC/104 stack.

## Power Input Connections

Power to the board must come from either the top or bottom PCIe/104 Type 2 bus connectors (**CN1** or **CN2**), or the auxiliary power connector (**CN3**). These connectors provide the required +5V DC voltage rail input to the cpuModule. While the RTD Intel E3800 Series CPU only requires +5 volts, +12V may optionally be connected to CN3 if it is required by any other device in the system.



**WARNING** While the PCI bus connector (**CN16**) has a +12V pin, it is not connected to the cpuModule, as the pin does not meet the cpuModule's current requirement. If the cpuModule is only connected to the power supply via the PCI connector, the cpuModule's LED will turn red, indicating that the +12V input rail is not present.

---



**Note** Although it is possible to power the cpuModule through the Auxiliary Power connector, the preferred method is to power it through the bus connector from a power supply in the stack. The cpuModule can have large current transients during operation, which make powering it through wires difficult. Powering through the bus eliminates such problems as voltage drop and lead inductance.

---



## Connecting to the Utility Port 2.0 Connector

The Utility Port 2.0 connector (**CN5**) implements the following interfaces:

- One USB 2.0 (Universal Serial Bus) port
- Speaker port (0.1 W output)
- Hardware Reset input
- Battery input for Real Time Clock
- Soft Power Button input

To use these interfaces, you must connect to the Utility Port 2.0 connector (**CN5**). The Utility Port 2.0 cable from the RTD cable kit provides a small speaker, two USB 2.0 ports for a keyboard and mouse, a push-button for resetting the system, a soft-power button, and a lithium battery to provide backup power for the real time clock.

Refer to *Utility Port 2.0 Connector (CN5)* on page 31 to connect devices to the Utility Port 2.0 connector.

## Booting the CMX34BT cpuModule for the First Time

You can now apply power to the cpuModule. If you press **ESC** on a keyboard while booting, the cpuModule will enter Setup. Once you have configured the cpuModule using Setup, save your changes and reboot. If you don't press **ESC**, the cpuModule will boot using the current settings.



**Note** You may miss the initial sign-on messages if your monitor takes a while to power on.

**Note** By default, cpuModules are shipped with a UEFI (Unified Extensible Firmware Interface) shell. When no other bootable device is installed in the system, the system will boot to it exclusively. This internal bootable shell may be disabled in the BIOS screen's boot menu.

---



**WARNING** Incorrect modifications to the BIOS can cause your system to break. If you are unsure of any changes made to the BIOS there is a **Load RTD Defaults** option under the **Exit** tab in the **SCU**. This option restores the BIOS to the default factory settings.

---





## Chapter 3 Connecting the cpuModule

This chapter provides information on all CMX34BT cpuModule connectors.

- Proper Grounding Techniques* — page 28
- Connector Locations* — page 28
- Auxiliary Power (CN3)* — page 30
- Utility Port 2.0 Connector (CN5)* — page 31
- SVGA Video Connector (CN18)* — page 34
- DisplayPort Connector (CN19)* — page 35
- Serial Port 1 (CN7) and Serial Port 2 (CN8)* — page 37
- Advanced Digital I/O (aDIO™) Port (CN6)* — page 43
- USB 2.0 Connectors (CN17 and CN27)* — page 44
- Ethernet (10/100/1000Base-T and -TX) Connectors (CN20 and CN30)* — page 46
- PCIe/104 Type 2 Bus (CN1 - Top and CN2 - Bottom)* — page 47
- Optional RTC Battery Input (CN13)* — page 51
- Fan Power (CN15)* — page 51

# Proper Grounding Techniques

Before removing the CMX34BT from its static bag, proper grounding techniques must be used to prevent electrostatic discharge (ESD) damage to the cpuModule. Common grounding procedures include an anti-static mat on a workbench, which may connect to an anti-static wrist strap (also known as an ESD wrist strap) on the wrist of the technician or engineer.

## Connector Locations

Figure 5 shows the connectors of the CMX34BT cpuModule.




Figure 5 CMX34BT cpuModule (top view)



**Note** Pin 1 of each connector is indicated by a white silk-screened square on the top side of the board and a square solder pad on the bottom side of the board. Pin 1 of the bus connectors match when stacking PC/104 modules.

**Table 7 CMX34BT Basic Connectors**

Connector	Function	Size and Pitch	Mating Connector
<b>CN1</b>	PCIe/104 Type 2 Bus (Top)	156-pin, 0.635mm	Samtec ASP-129646-03
<b>CN2</b>	PCIe/104 Type 2 Bus (Bottom)	156-pin, 0.635mm	Samtec ASP-129637-03
<b>CN3</b>	Auxiliary Power	1x12, 0.1"	FCI 65039-025LF
<b>CN5</b>	Utility Port 2.0	2x5, 0.1"	3M 89110-0001
<b>CN6</b>	aDIO	2x8, 0.1"	3M 89116-0001
<b>CN7</b>	Serial Port 1 (COM1&3)	2x5, 0.1"	3M 89110-0001
<b>CN8</b>	Serial Port 2 (COM2&4)	2x5, 0.1"	3M 89110-0001
<b>CN13</b>	RTC Battery Input (optional)	1x2, 2mm	FCI 69305-002LF
<b>CN15</b>	Optional Fan connector	1x3, 2mm	FCI 69305-003LF
<b>CN17</b>	USB 2.0	2x5, 0.1"	3M 89110-0001
<b>CN18</b>	Video (SVGA)	2x5, 0.1"	3M 89110-0001
<b>CN19</b>	DisplayPort	Molex P/N Series 47272-xxxx	Molex P/N Series 68783-xxxx
<b>CN20</b>	Ethernet	2x5, 0.1"	3M 89110-0001
<b>CN27</b>	USB 2.0	2x5, 0.1"	3M 89110-0001
<b>CN30</b>	Ethernet	2x5, 0.1"	3M 89110-0001

## Auxiliary Power (CN3)

The Auxiliary Power connector (**CN3**) can be used to supply power to devices that are attached to the cpuModule. These devices include hard drive, front-end boards for data acquisition systems, and other devices.

Power can also be conveyed to the module through the Auxiliary Power connector (**CN3**). The Intel E3800 Series cpuModule only requires +5 VDC and ground for operation. +12 V may optionally be connected to CN3 if it is required by any other device in the system.



**Note** Although it is possible to power the cpuModule through the Auxiliary Power connector, the preferred method is to power it through the bus connector from a power supply in the stack. The cpuModule can have large current transients during operation, which make powering it through wires difficult. Powering through the bus eliminates such problems as voltage drop and lead inductance.



**WARNING** System configurations which are powered using CN3 should **only** be used power the CPU. The connector is not intended to power configurations which consist of peripheral cards.

If using the Auxiliary Power connector to power the system, care must be taken to ensure good power connections. The power and ground leads must be twisted together, or as close together as possible to reduce lead inductance. A separate lead must be used for each of the power pins. All 5V pins and all ground pins must be connected. Do not use wire smaller than 20 gauge, and take care to ensure the length of the wire does not exceed 2 ft. The power supply solution must be verified by measuring voltage at the Auxiliary Power Connector and verifying that it meets the input voltage specifications. The voltage at the connector should be checked with an oscilloscope while the system is operational.



**WARNING** This 12-pin power connector is **not** compatible with previous generations of RTD cpuModules.

**WARNING** If you connect power incorrectly, the module will almost certainly be destroyed. Please verify power connections to the module before applying power.

**Table 8 Auxiliary Power Connector (CN3)**

Pin	Signal	Function
1	GND	Ground
2	+5 V	+5 Volts DC
3	+5 V	+5 Volts DC
4	GND	Ground
5	GND	Ground
6	+12 V <sup>1</sup>	+12 Volts DC
7	+12 V <sup>1</sup>	+12 Volts DC
8	GND	Ground
9	GND	Ground
10	+5 V	+5 Volts DC
11	+5 V	+5 Volts DC
12	GND	Ground

1. +12 V not required for operation of the cpuModule

## Utility Port 2.0 Connector (CN5)

The Utility Port 2.0 connector implements the following functions:

- 1x USB 2.0 (Universal Serial Bus) Port
- Speaker port (0.1 W output)
- Hardware Reset input
- Soft Power Button input
- Battery input for Real Time Clock

Table 9 provides the pinout of the Utility Port 2.0 connector.

**Table 9 Utility Port 2.0 Connector (CN5)**

Pin	Signal	Function	In/Out
1	SPKR	Speaker Output (open collector)	out
2	PWR	+5 V	out
3	RESET#	Manual Push-Button Reset	in
4	DATA-	Bidirectional data line for USB1	in/out
5	PWRSW#	Soft Power Button	in
6	DATA+	Bidirectional data line for USB1	in/out
7	GND	Ground	out
8	GND	Ground	out
9	BAT	RTC Battery Input	in
10	Shield GND	Shield Ground	out



**WARNING** The pinout of the Utility Port 2.0 connector is **not** compatible with previous generations of RTD cpuModules. Attaching a legacy Utility Port harness to the Utility Port 2.0 connector may damage or destroy the cpuModule.

Facing the connector pins, the pinout is:

9	7	5	3	1
BAT	GND	PWRSW#	RESET#	SPKR
Shield GND	GND	DATA+	DATA-	PWR
10	8	6	4	2

## USB 2.0 Connector

One USB 2.0 compliant connector is available on connector **CN5**. Table 9 provides the pinout of the USB connector.



**Note** For proper operation at USB 2.0 speeds, be sure to use a cable that is rated for USB 2.0, such as the cable kit supplied by RTD.

---

## Speaker

A speaker output is available on pins 1 and 2 of the Utility Port 2.0 connector. These outputs are controlled by a transistor to supply 0.1 W of power to an external speaker. The external speaker should have 8 Ohm impedance and be connected between pins 1 and 2.

## System Reset

Pin 3 of the Utility Port 2.0 connector allows connection of an external push-button to manually reset the system. The push-button should be normally open, and connect to ground when pushed. The type of reset generated by this button can be set in the BIOS configuration utility.

## Soft Power Button

Pin 5 of the Utility Port 2.0 connector allows connection of an external push-button to send a soft power signal to the system. The push-button should be normally open, and connect to ground when pushed. For more information on the modes of the Soft Power Button, refer to the *Power Management* section in Chapter 4, *Using the cpuModule*



## Battery

Pin 9 of the Utility Port 2.0 connector is the connection for an external backup battery. This battery is used by the cpuModule when system power is removed in order to preserve the date and time of the real time clock.

Connecting a battery is only required to maintain time when power is completely removed from the cpuModule. A battery is not required for board operation.



**WARNING** *The optional RTC battery input connector (CN13) should be left unconnected if the multi-function connector (CN5) has a battery connected to pin 9.*

---

## SVGA Video Connector (CN18)

Table 10 provides the pinout of the video connector.

**Table 10 SVGA Video Connector (CN18)**

Pin	Signal	Function	In/Out
1	VSYNC	Vertical Sync	out
2	HSYNC	Horizontal Sync	out
3	DDCSCL	Monitor Communications Clock	out
4	RED	Red Analog Output	out
5	DDCSDA	Monitor Communications Data	bidirectional
6	GREEN	Green Analog Output	out
7	PWR	+5 V	out
8	BLUE	Blue Analog Output	out
9	GND	Ground	out
10	GND	Ground	out

Facing the connector pins of the SVGA Video connector (**CN18**), the pinout is:

9	7	5	3	1
GND	PWR	DDCSDA	DDCSCL	VSYNC
GND	BLUE	GREEN	RED	HSYNC
10	8	6	4	2

## DisplayPort Connector (CN19)

The DisplayPort connector on the CMX34BT cpuModule is a standard PC DisplayPort connector complete with latch holes to provide a rugged connecting solution for latching DisplayPort cables.

The DisplayPort supports all mandatory features of the VESA Embedded DisplayPort (eDP) 1.3 standard and supports audio over the connection. Full bandwidth transmission is supported over a two meter cable, with reduced bandwidth transmission supported up to a length of 15 meters.

The connection can directly output single-link HDMI and DVI signals by using a simple passive adapter. Passive adapters achieve HDMI and DVI signaling by adjusting the lower signal levels output by the connector.

Table 11 provides the pinout of the DisplayPort connector.

**Table 11 DisplayPort Connector (CN19)**

Pin	Signal	Standard Function	DVI / HDMI mode <sup>1</sup>	In/Out
1	LN0+	Main Link, Lane 0 (positive)	TMDS Channel 2 (positive)	out
2	GND	Ground	Ground	out
3	LN0-	Main Link, Lane 0 (negative)	TMDS Channel 2 (negative)	out
4	LN1+	Main Link, Lane 1 (positive)	TMDS Channel 1 (positive)	out
5	GND	Ground	Ground	out
6	LN1-	Main Link, Lane 1 (negative)	TMDS Channel 1 (negative)	out
7	LN2+	Main Link, Lane 2 (positive)	TMDS Channel 0 (positive)	out
8	GND	Ground	Ground	out
9	LN2-	Main Link, Lane 2 (negative)	TMDS Channel 0 (negative)	out
10	LN3+	Main Link, Lane 3 (positive)	TMDS Clock (positive)	out
11	GND	Ground	Ground	out
12	LN3-	Main Link, Lane 3 (negative)	TMDS Clock (negative)	out
13	CFG1	Configuration Pin 1	Cable Adapter Detect	out
14	CFG2	Configuration Pin 2	Consumer Electronics Control <sup>2</sup>	out
15	AUX+	Auxiliary Channel (positive)	DDC Clock	in/out
16	GND	Ground	Ground	out
17	AUX-	Auxiliary Channel (negative)	DDC Data	in/out
18	HPD	Hot Plug Detect	Hot Plug Detect	in
19	DPG	Return for DPV	Return for DPV	out
20	DPV	+3.3V DC Power	+3.3V DC Power	out

1. Requires special passive adapter

2. HDMI mode only

Facing the connector pins of the DisplayPort connector (**CN19**), the pinout is:

19	17	15	13	11	9	7	5	3	1
DPG	AUX-	AUX+	CFG1	GND	LN2-	LN2+	GND	LN0-	LN0+
DPV	HPD	GND	CFG2	LN3-	LN3+	GND	LN1-	LN1+	GND
20	18	16	14	12	10	8	6	4	2

## Serial Port 1 (CN7) and Serial Port 2 (CN8)

Serial Port 1 (COM1) is implemented on connector **CN7**, and Serial Port 2 (COM2) is implemented on connector **CN8**. The serial ports are normally configured as PC compatible full-duplex RS-232 ports, but you may use the BIOS Setup program to reconfigure these ports as half-duplex RS-422 or full-duplex RS-422 or RS-485. If you reconfigure the ports, you must also select the I/O address and corresponding interrupt using Setup. Table 12 provides the standard I/O addresses and corresponding interrupts.

**Table 12 Serial Port Settings**

I/O Address (hex)	IRQ
03F8	IRQ4
02F8	IRQ3
03E8	IRQ4
02E8	IRQ3

### Serial Port UART

The serial ports are implemented with a 16550/16750-compatible UART (Universal Asynchronous Receiver/Transmitter). This UART is capable of baud rates up to 115.2 kbaud, and includes a 64-byte FIFO. Refer to any standard PC-AT hardware reference for the register map of the UART.

It is possible to change the slew rate for the UARTs of the cpuModule to allow the serial ports to operate at higher speeds than 115200 bps. For more information see [Chapter 4 - "Non-Standard Serial Port Modes"](#).

### RS-232 Serial Port (Default)

The default serial port mode is full-duplex RS-232. With this mode enabled, the serial port connectors must be connected to RS-232 compatible devices. Table 13 provides the serial port connector pinout and shows how to connect to an external DB-25 or DB-9 compatible serial connector.

**Table 13 Serial Port in RS-232 Mode**

Pin	Signal	Function	In/Out	DB-25	DB-9
1	DCD	Data Carrier Detect	in	8	1
2	DSR	Data Set Ready	in	6	6
3	RXD	Receive Data	in	3	2
4	RTS	Request To Send	out	4	7
5	TXD	Transmit Data	out	2	3
6	CTS	Clear To Send	in	5	8
7	DTR	Data Terminal Ready	out	20	4
8	RI	Ring Indicate	in	22	9
9	GND	Signal Ground	—	7	5
10	GND	Signal Ground	—	—	—

Facing the serial port's connector pins, the pinout is:

9	7	5	3	1
GND	DTR	TXD	RXD	DCD
GND	RI	CTS	RTS	DSR
10	8	6	4	2

## RS-422 or RS-485 Serial Port

You may use the BIOS setup utility to configure the serial ports as RS-422 or RS-485. In this case, you must connect the serial port to an RS-422 or RS-485 compatible device.

When using RS-422 mode, you can use the serial ports in either half-duplex (two-wire) or full-duplex (four-wire) configurations.



**Note** The cpuModule has a 120 Ohm termination resistor. Termination is usually necessary on all RS-422 receivers and at the ends of the RS-485 bus. Termination resistors can be enabled in the BIOS setup utility.

When using full-duplex in RS-422 mode, connect the ports as shown in Table 14.

**Table 14 Full-Duplex Connections**

Port 1	Port 2
RXD+	TXD+
TXD+	RXD+
RXD-	TXD-
TXD-	RXD-

In RS-485 mode, the connection of the ports is always half-duplex, as the transceivers' transmitters are connected to the receivers internally.

## RS-422 Mode Pinout

Table 15 provides the serial port connector pinout when RS-422 mode is enabled.

**Table 15 Serial Port in RS-422 Mode**

Pin	Signal	Function	In/Out	DB-9
1	TXD-	Transmit Data (-)	out	1
2	—	Reserved	—	6
3	TXD+	Transmit Data (+)	out	2
4	—	Reserved	—	7
5	RXD+	Receive Data (+)	in	3
6	—	Reserved	—	8
7	RXD-	Receive Data (-)	in	4
8	—	Reserved	—	9
9	GND	Signal Ground	—	5
10	GND	Signal Ground	—	—

Facing the serial port connector, the pinout is:

9	7	5	3	1
GND	RXD-	RXD+	TXD+	TXD-
GND	Rsvd	Rsvd	Rsvd	Rsvd
10	8	6	4	2



**WARNING** The pinout of the COM ports in RS-422 mode is **not** compatible with previous generations of RTD cpuModules.

## RS-485 Mode Pinout

Table 16 provides the serial port connector pinout when RS-482 mode is enabled

**Table 16 Serial Port in RS-485 Mode**

Pin	Signal	Function	In/Out	DB-9
1	D-	Data (-)	in/out	1
2	—	Reserved	—	6
3	D+	Data (+)	in/out	2
4	—	Reserved	—	7
5	—	Reserved	—	3
6	—	Reserved	—	8
7	—	Reserved	—	4
8	—	Reserved	—	9
9	GND	Signal Ground	—	5
10	GND	Signal Ground	—	—

Facing the serial port connector, the pinout is:

9	7	5	3	1
GND	Rsvd	Rsvd	D+	D-
GND	Rsvd	Rsvd	Rsvd	Rsvd
10	8	6	4	2



**WARNING** The pinout of the COM ports in RS-485 mode is **not** compatible with previous generations of RTD cpuModules.



**Note** When using the serial port in RS-485 mode, the serial transmitters are enabled and disabled under software control. The transmitters are enabled by manipulating the Request To Send (RTS\*) signal of the serial port controller. This signal is controlled by writing bit 1 of the Modem Control Register (MCR) as follows:

- If MCR bit 1 = 1, then RTS\* = 0, and serial transmitters are disabled
- If MCR bit 1 = 0, then RTS\* = 1, and serial transmitters are enabled

**Note** For more information on the serial port registers, including the MCR, refer to the Serial Port Programming reference in Appendix D.



## Dual Serial Port Modes

The serial port connectors can be configured as dual serial ports in the BIOS. This enhancement in dual RS-232 comes at the cost of losing the DSR and DTR signals, which are only available in single RS-232 mode.

The mapping between the connectors and COM port numbers is shown in Table 17. The supported combinations of serial port modes are listed in Table 18, which also includes a reference to the corresponding connector pinout.

**Table 17 Dual Serial Port Connections**

Connector	COM A	COM B
CN7	COM 1	COM 3
CN8	COM 2	COM 4

**Table 18 Dual Serial Port Modes**

COM A	COM B	Pinout Reference	Echo Mode
RS-232	RS-232	Table 19	—
RS-422	RS-422	Table 20	—
RS-485	RS-485	Table 21	echo cancelled
RS-485	RS-485	Table 20	with echo <sup>1</sup>

1. Dual RS-485 mode with echo uses dual RS-422 mode pinout



**WARNING** The dual serial port mode pinouts of the COM ports are **not** compatible with previous generations of RTD cpuModules.



**Note** The cpuModule has 120 Ohm termination resistors. Termination is usually necessary on all RS-422 receivers and at the ends of the RS-485 bus. Termination resistors can be enabled in the BIOS setup utility. When termination is enabled in dual port mode, it is enabled for both ports.

**Table 19 COM A (RS-232) and COM B (RS-232)**

Pin	Signal	Function	In/Out	DB-9
1	DCD1	COM A - Data Carrier Detect	in	1
2	CTS1	COM A - Clear To Send	in	6
3	RXD1	COM A - Receive Data	in	2
4	TXD2	COM B - Transmit Data	out	7
5	TXD1	COM A - Transmit Data	out	3
6	RXD2	COM B - Receive Data	in	8
7	RTS1	COM A - Request To Send	out	4
8	RI1	COM A - Ring Indicate	in	9

**Table 19 COM A (RS-232) and COM B (RS-232)**

Pin	Signal	Function	In/Out	DB-9
9	GND	Signal Ground	—	5
10	GND	Signal Ground	—	—

**Table 20 COM A (RS-422) and COM B (RS-422)<sup>1</sup>**

Pin	Signal	Function	In/Out	DB-9
1	TXD1-	COM A - Transmit Data (-)	out	1
2	TXD2-	COM B - Transmit Data (-)	out	6
3	TXD1+	COM A - Transmit Data (+)	out	2
4	TXD2+	COM B - Transmit Data (+)	out	7
5	RXD1+	COM A - Receive Data (+)	in	3
6	RXD2+	COM B - Receive Data (+)	in	8
7	RXD1-	COM A - Receive Data (-)	in	4
8	RXD2-	COM B - Receive Data (-)	in	9
9	GND	Signal Ground	—	5
10	GND	Signal Ground	—	—

1. Dual RS-485 mode with echo uses dual RS-422 mode pinout

**Table 21 COM A (RS-485) and COM B (RS-485)**

Pin	Signal	Function	In/Out	DB-9
1	D1-	COM A - Data (-)	in/out	1
2	D2-	COM B - Data (-)	in/out	6
3	D1+	COM A - Data (+)	in/out	2
4	D2+	COM B - Data (+)	in/out	7
5	—	Reserved	—	3
6	—	Reserved	—	8
7	—	Reserved	—	4
8	—	Reserved	—	9
9	GND	Signal Ground	—	5
10	GND	Signal Ground	—	—

## Advanced Digital I/O (aDIO™) Port (CN6)

Connector **CN6** is configured as an aDIO port. aDIO is 12 digital bits configured as 8-bit programmable and 4-bit port programmable I/O, providing any combination of inputs and outputs. Match, event, and strobe interrupt modes mean no more wasting valuable processor time polling digital inputs. Interrupts are generated when the 8-bit programmable digital inputs match a pattern, or on any value change event. Bit masking allows selecting any subgroup of 8 bits. The strobe input latches data into the bit programmable port and generates an interrupt. Refer to *Advanced Digital I/O Ports (aDIO™)*—page 58 for information on programming the aDIO.

**Table 22 aDIO Pinout**

CN6 Pin	Function	CN6 Pin	Function
1	P0-0	2	P0-1
3	P0-2	4	P0-3
5	P0-4	6	P0-5
7	P0-6	8	P0-7
9	strobe 0	10	strobe 1
11	P1-0	12	P1-1
13	P1-2	14	P1-3
15	GND	16	+5 V <sup>1</sup>

1. Available during standby.

## USB 2.0 Connectors (CN17 and CN27)

Four USB 2.0 compliant connectors are available on connectors **CN17** and **CN27**. Table 23 provides the pinout of the USB connectors.

**Table 23 USB Connector (CN17)**

Pin	Signal	Function	In/Out
1	VCC1	Supply +5 V to USB1	out
2	VCC2	Supply +5 V to USB2	out
3	DATA1-	Bidirectional data line for USB1	in/out
4	DATA2-	Bidirectional data line for USB2	in/out
5	DATA1+	Bidirectional data line for USB1	in/out
6	DATA2+	Bidirectional data line for USB2	in/out
7	GND	Ground	out
8	GND	Ground	out
9	Shield GND	Shield Ground	out
10	Shield GND	Shield Ground	out

**Table 24 USB Connector (CN27)**

Pin	Signal	Function	In/Out
1	VCC3	Supply +5 V to USB3	out
2	VCC4	Supply +5 V to USB4	out
3	DATA3-	Bidirectional data line for USB3	in/out
4	DATA4-	Bidirectional data line for USB4	in/out
5	DATA3+	Bidirectional data line for USB3	in/out
6	DATA4+	Bidirectional data line for USB4	in/out
7	GND	Ground	out
8	GND	Ground	out
9	Shield GND	Shield Ground	out
10	Shield GND	Shield Ground	out



**Note** For proper operation at USB 2.0 speeds, be sure to use a cable that is rated for USB 2.0, such as the cable kit supplied by RTD.

Facing the connector pins, the pinout of **CN17** is:

9	7	5	3	1
Shield GND	GND	DATA1+	DATA1-	VCC1
Shield GND	GND	DATA2+	DATA2-	VCC2
10	8	6	4	2

Facing the connector pins, the pinout of **CN27** is:

9	7	5	3	1
Shield GND	GND	DATA3+	DATA3-	VCC3
Shield GND	GND	DATA4+	DATA4-	VCC4
10	8	6	4	2

## Ethernet (10/100/1000Base-T and -TX) Connectors (CN20 and CN30)

This connector provides a 10/100/1000Base-T Ethernet connection. Table 25 provides the pinout of the Ethernet connector. For 1000Base-T, all four pairs are used for transmit and receive.

To use the onboard 10/100/1000 Ethernet controller, Ethernet must be enabled in the BIOS.

When enabled, the multi-color LED will blink to indicate an Ethernet connection. For more information, refer to the *Multi-Color LED* section on page 67.

**Table 25 Ethernet Connectors (CN20 and CN30)**

RJ-45 Pin	10-Pin DIL Pin	Signal	Function
3	1	B+ (RX+)	Receive+ (10/100)
6	2	B- (RX-)	Receive- (10/100)
4	3	C+	
5	4	C-	
1	5	A+ (TX+)	Transmit+ (10/100)
2	6	A- (TX-)	Transmit- (10/100)
7	7	D+	
8	8	D-	
—	9	AGND	Ethernet Ground
—	10	AGND	Ethernet Ground

9	7	5	3	1
AGND	D+	A+	C+	B+
AGND	D-	A-	C-	B-
10	8	6	4	2

## PCIe/104 Type 2 Bus (CN1 - Top and CN2 - Bottom)

Connectors **CN1** and **CN2** carry the signals of the PCIe/104 PCIe bus. These signals match definitions found in the **PCI/104-Express & PCIe/104 Specification Version 3.1** from the PC/104 Embedded Consortium. Table 26 lists the pinouts of the PC/104-Express bus connector.



**WARNING** Not all PCIe cards are compatible with the PCIe/104 Type 2 connector. Be sure that all of the boards attached to this bus are compatible before powering the system.

**Table 26 PCIe/104 Type 2 Bus Signal Assignments (Top View)<sup>1</sup>**

Pin	Signal	Signal	Pin
1	USB_OC#	PE_RST#	2
3	+3.3V <sup>2</sup>	+3.3V <sup>2</sup>	4
5	USB_1p	USB_0p	6
7	USB_1n	USB_0n	8
9	GND	GND	10
11	PEx1_1Tp (CN2 only)	PEx1_0Tp (CN2 only)	12
13	PEx1_1Tn (CN2 only)	PEx1_0Tn (CN2 only)	14
15	GND	GND	16
17	PEx1_2Tp (CN2 only)	PEx1_3Tp (CN2 only)	18
19	PEx1_2Tn (CN2 only)	PEx1_3Tn (CN2 only)	20
21	GND	GND	22
23	PEx1_1Rp (CN2 only)	PEx1_0Rp (CN2 only)	24
25	PEx1_1Rn (CN2 only)	PEx1_0Rn (CN2 only)	26
27	GND	GND	28
29	PEx1_2Rp (CN2 only)	PEx1_3Rp (CN2 only)	30
31	PEx1_2Rn (CN2 only)	PEx1_3Rn (CN2 only)	32
33	GND	GND	34
35	PEx1_1Clkp (CN2 only)	PEx1_0Clkp (CN2 only)	36
37	PEx1_1Clkn (CN2 only)	PEx1_0Clkn (CN2 only)	38
39	+5V_STBY	+5V_STBY	40
41	PEx1_2Clkp (CN2 only)	PEx1_3Clkp (CN2 only)	42
43	PEx1_2Clkn (CN2 only)	PEx1_3Clkn (CN2 only)	44
45	CPU_DIR	PWRGOOD	46
47	Reserved	Reserved	48
49	Reserved	Reserved	50
51	Reserved	PSON#	52

+5 Volts

**Table 26 PCIe/104 Type 2 Bus Signal Assignments (Top View)<sup>1</sup>**

Pin	Signal	Signal	Pin
53	STK0	STK1	54
55	GND	GND	56
57	Reserved	Reserved	58
59	Reserved	Reserved	60
61	GND	GND	62
63	Reserved	Reserved	64
65	Reserved	Reserved	66
67	GND	GND	68
69	Reserved	Reserved	70
71	Reserved	Reserved	72
73	GND	GND	74
75	Reserved	Reserved	76
77	Reserved	Reserved	78
79	GND	GND	80
81	Reserved	SATA_0Tp (CN1 only)	82
83	Reserved	SATA_0Tn (CN1 only)	84
85	GND	GND	86
87	Reserved	Reserved	88
89	Reserved	Reserved	90
91	GND	GND	92
93	Reserved	Reserved	94
95	Reserved	Reserved	96
97	GND	GND	98
99	Reserved	Reserved	100
101	Reserved	Reserved	102
103	GND	GND	104

+5 Volts



**Table 26 PCIe/104 Type 2 Bus Signal Assignments (Top View)<sup>1</sup>**

Pin	Signal	Signal	Pin
105	STK2	Reserved	106
107	GND	GND	108
109	Reserved	Reserved	110
111	Reserved	Reserved	112
113	GND	GND	114
115	Reserved	Reserved	116
117	Reserved	Reserved	118
119	GND	GND	120
121	Reserved	Reserved	122
123	Reserved	Reserved	124
125	GND	GND	126
127	Reserved	Reserved	128
129	Reserved	Reserved	130
131	GND	GND	132
133	Reserved	SATA_0Rp (CN1 only)	134
135	Reserved	SATA_0Rn (CN1 only)	136
137	GND	GND	138
139	Reserved	Reserved	140
141	Reserved	Reserved	142
143	GND	GND	144
145	Reserved	Reserved	146
147	Reserved	Reserved	148
149	GND	GND	150
151	Reserved	Reserved	152
153	Reserved	Reserved	154
155	GND	GND	156

+12 Volts<sup>3</sup>

1. Signals marked with (#) are active low.
2. +3.3V is not required for board operation. For power input requirements, see Table 3.
3. +12 Volts not required for operation.

## PCIe/104 Type 2 Compatibility

The PCIe/104 Type 2 connector is compatible with any PCI/104-Express or PCIe/104 peripheral module that does not use the x16 Link. This includes any card that uses the PCIe x1 links, USB, or a power supply. In addition, this connector can be used to add SATA devices to the system.

If a card is installed that is not compatible with the Type 2 connector, the CPU will keep the system in soft-off, and the LED will be Cyan to indicate that there is a Bus Stacking Error.

## PCIe Link Configuration

This cpuModule supports a total of four PCIe x1 links for system expansion, all of which are on the bottom-side PCIe/104 connector, **CN2**. Three of the links on **CN2** are connected directly to the chipset. The fourth link is connected through a PCIe packet switch, which shares the bandwidth of a single x1 link back to the chipset with the onboard PCIe-to-PCI bridge and the gigabit Ethernet controller. Table 27 below shows the configuration of the PCIe x1 links on CN1 and CN2.

**Table 27 CN2 Link Configuration**

Link	Location	Connection
Link 3	Closest to CPU	Direct
Link 2		Direct
Link 1		Direct
Link 0	Farthest from CPU	Shared

## Optional RTC Battery Input (CN13)

The optional RTC battery input is the connection for an external backup battery. This battery is used by the cpuModule when system power is removed in order to preserve the date and time of the real time clock.

Connecting a battery is only required to maintain time when power is completely removed from the cpuModule. A battery is not required for board operation.

**Table 28 Optional RTC Battery Input (CN13)**

Pin	Signal	Function
1	BAT	RTC Battery Input
2	GND	Ground



**WARNING** This optional RTC battery connector (CN13) should be left unconnected if the Utility Port 2.0 connector (CN5) has a battery connected.

---

## Fan Power (CN15)

While a fan is not required for board operation, the optional fan connector provides the means for a fan to be connected to the system. The pinout for the connector is shown below.

**Table 29 Optional Fan Connector (CN15)**

Pin	Signal	Function
1	+5 V	Fan power
2	GND	Ground
3	Reserved	



**WARNING** The fan connector (CN15) should be left unconnected if it is not used.

---





## Chapter 4 Using the cpuModule

This chapter provides information for users who wish to develop their own applications programs for the CMX34BT cpuModule.

This chapter includes information on the following topics:

*The RTD Enhanced BIOS* — page 54

*Operating System Specific Usage* — page 56

*Non-Standard Serial Port Modes* — page 57

*Advanced Digital I/O Ports (aDIO™)* — page 58

*SATA Controller Configuration* — page 62

*Watchdog Timer Control* — page 63

*Thermal Management* — page 64

*Power Management* — page 65

*Multi-Color LED* — page 67

*Features and Settings That Can Affect Boot Time* — page 70

*System Recovery* — page 71

# The RTD Enhanced BIOS

The RTD Enhanced BIOS is software that interfaces hardware-specific features of the cpuModule to an operating system (OS). Physically, the BIOS software is stored in a Flash EPROM on the cpuModule. Functions of the BIOS are divided into two parts.

The first part of the BIOS is known as POST (power-on self-test) software, and it is active from the time power is applied until an OS boots (begins execution). POST software performs a series of hardware tests, sets up the machine as defined in Setup, and begins the boot of the OS.

The second part of the BIOS is known as the CORE BIOS. It is the normal interface between cpuModule hardware and the OS which is in control. It is active from the time the OS boots until the cpuModule is turned off. The CORE BIOS provides the system with a series of software interrupts to control various hardware devices.

## Configuring the RTD Enhanced BIOS

The cpuModule Setup program allows you to customize the cpuModule's configuration. Selections made in Setup are stored on the board and are read by the BIOS at power-on.

## Entering the BIOS Setup through the Graphical BIOS Menu

You can run Setup by rebooting the cpuModule and repeatedly pressing the **ESC** key. This will bring you to a graphical BIOS menu with several options described in the table below.

To enter Setup, navigate to the **SCU** option with the arrow keys, and press **Enter**.



**Table 30 Graphical BIOS Menu Options**

Key	Function
Continue	Exit the graphical menu, and proceed with booting
Boot Manager	Select a device to boot to during the current power cycle, and override the selected boot device order in the Setup
Device Management	Set the primary video BIOS during the current power cycle, and view a list of the system's detected devices (disk, video, network, input, etc.)
Boot From File	Displays a list of bootable files in the system
SCU	Traditional BIOS Setup

## Field Selection

To move between fields in Setup, use the keys listed below. When you are finished with Setup, save your changes and exit. The system will automatically reboot.

**Table 31 Setup Keys**

Key	Function
F1	Help
→, ←, ↓, ↑	Move between fields
F5, F6	Selects next/previous values in fields
Enter	Go to the submenu for the field
ESC	To previous menu then to exit menu
F9	Load Setup defaults
F10	Save settings and exit Setup

## Main Menu Setup Fields

The following is a list of Main Menu Setup fields.

**Table 32 Main Menu Setup Fields**

Field	Active Keys	Selections
Main	Press <b>Enter</b> to select	Access system information such as the cpuModule's serial number, CPU speed and type, BIOS version, FPGA version, and CMOS time and date settings
Advanced	Press <b>Enter</b> to select	Setup advanced RTD cpuModule features, including boot options, aDIO and serial port configuration, and miscellaneous feature control.
Security	Press <b>Enter</b> to select	Setup the supervisor and access password
Boot	Press <b>Enter</b> to select	Set the system boot sequence
Power	Press <b>Enter</b> to select	Set up various power savings modes
Exit	Press <b>Enter</b> to select	Save or discard changes and exit the BIOS, or load the default BIOS settings



**Note** Future BIOS versions may have slightly different setup menus and options.

**Note** The **Main** page shows the cpuModule's **serial number**, **BIOS Version**, and **FPGA Version**. These numbers can be useful if you need techsupport for your cpuModule.



**WARNING** Incorrect modifications to the BIOS can cause your system to break. If you are unsure of any changes made to the BIOS there is a **Load RTD Defaults** option under the **Exit** tab in the **SCU**. This option restores the BIOS to the default factory settings.

# Operating System Specific Usage

## Windows®

The CMX34BT is fully supported under Windows 10 and Windows 7. Both 32 bit and 64 bit editions are supported. Drivers for onboard peripherals such as video and Ethernet are provided on the companion DVD that is shipped with the board. Updated drivers may be available for download from the RTD website. ([www.rtd.com](http://www.rtd.com))

## Linux®

The CMX34BT is fully supported with Linux kernel version 3.11 and onward. Earlier versions of the kernel may not contain drivers for all chipset features (most notably SATA), and may not work as expected.

At the time of publication, RTD has validated openSUSE 13.1, openSUSE 13.2, and Ubuntu 15.10 (all 64-bit) on this platform. However, any standard PC Linux distribution with a 3.11 or newer kernel is expected to work.

## UEFI OS Installations

When dealing with UEFI OS installations, the BIOS setting for “EFI/Legcy Device Order” will need to be changed to “EFI devices first”. The default boot order is to boot to “Legacy devices first”, which will render the OS unbootable after an installation.



## Non-Standard Serial Port Modes

It is possible to change the input clock rate for the UARTs of the cpuModule to allow the serial ports to operate at higher speeds than 115,200 bps. This is accomplished by modifying the baud rate multiplier for each serial port.

Non-standard baud rates are supported for all COM port modes of the CMX34BT.:

**Table 33 Baud Rate Multiplier Registers**

Connector	Port	Address Range (hex)
CN7 (A)	COM 1	EE0–EE1h
CN7 (B)	COM 3	EE2–EE3h
CN8 (A)	COM 2	EE4–EE5h
CN8 (B)	COM 4	EE6–EE7h

To set an alternate maximum baud rate for a serial port, write the value which corresponds to the desired multiplier to the port's baud rate multiplier register:

**Table 34 Baud Rate Multipliers**

Value	Maximum Baud Rate	
	bps	Multiplier
0x0E28	115,200	1x
0x38A0	460,800	4x
0x713F	921,600	8x
0x7AE1	1,000,000	8.7x



**Note** When using the non-standard high speed serial port modes, it is highly recommended to use hardware flow control, whenever possible.

## Advanced Digital I/O Ports (aDIO™)

This board supports 12 bits of TTL/CMOS compatible digital I/O (TTL signaling). These I/O lines are grouped into two ports, Port 0 and Port 1. Port 0 is bit programmable; Port 1 is byte programmable. Port 0 supports RTD's Advanced Digital Interrupt modes. The three modes are strobe, match and event. Strobe mode generates an interrupt and latches Port 0 when the strobe input transitions from low to high. Match mode generates an interrupt when an 8-bit pattern is received in parallel that matches the match mask register. Event mode generates an interrupt when a change occurs on any bit. In any mode, masking can be used to monitor selected lines.

When the CPU boots, all digital I/O lines are programmed as inputs, meaning that the digital I/O line's initial state is undetermined. If the digital I/O lines must power up to a known state, an external 10 k-Ohm resistor must be added to pull the line high or low.

The 8-bit control read/write registers for the digital I/O lines are located from I/O address EC0h to EC3h. These registers are written to zero upon power up. From EC0h to EC3h, the name of these registers are **Port 0 data**, **Port 1 data**, **Multi-Function**, and **DIO-Control** register.



**Note** While the 16-pin aDIO connector is pin-for-pin compatible with previous generations of RTD cpuModules (such as the Montevina series), the hardware is slightly different, and requires that writes and reads to/from the aDIO ports happen no more than once per millisecond. Migrating legacy software to the E3800 Series that utilizes RTD's Advanced Digital I/O may require that you add this delay prior to all reads and writes.

**Note** RTD provides drivers that support the aDIO interface on popular operating systems. RTD recommends using these drivers instead of accessing the registers directly.

### Digital I/O Register Set

**Table 35 Port 0 Data I/O Address EC0h**

D7	D6	D5	D4	D3	D2	D1	D0
P0.7	P0.6	P0.5	P0.4	P0.3	P0.2	P0.1	P0.0

Port 0 Data register is a read/write bit direction programmable register. A particular bit can be set to input or output. A read of an input bit returns the value of port 0. A read of an output bit returns the last value written to Port 0. A write to an output bit sends that value to port 0.

**Table 36 Port 1 Data I/O Address EC1h**

D7	D6	D5	D4	D3	D2	D1	D0
Reserved	Reserved	Reserved	Reserved	P1.3	P1.2	P1.1	P1.0


Port 1 Data register is a read/write byte direction programmable register. A read on this register when it is programmed to input will read the value at the aDIO connector. A write on this register when it is programmed as output will write the value to the aDIO connector. A read on this register when it is set to output will read the last value sent to the aDIO connector.

**Table 37 Multi-Function I/O Address EC2h**


D7	D6	D5	D4	D3	D2	D1	D0
----	----	----	----	----	----	----	----

The multi-function register is a read/write register whose contents are set by the DIO-Control register. See the DIO-Control register description for a description of this register.

**Table 38 DIO-Control I/O Address EC3h—Read Access**



**Table 39 DIO-Control I/O Address EC3h—Write Access**



**Table 40 Multi-Function at Address EC2h<sup>1</sup>**

read/write	00 clear	X	X	X	X	X	X	X	X
0 in, 1 out	01 Port 0 direction	I/O	I/O	I/O	I/O	I/O	I/O	I/O	I/O
0 no mask, 1 mask	10 DIO mask	M7	M6	M5	M4	M3	M2	M1	M0
read/write	11 compare	C7	C6	C5	C4	C3	C2	C1	C0

1. Contents based on bits D0 and D1 of DIO-Control.

**Clear Register:**

A read to this register Clears the IRQs and a write to this register sets the DIO-Compare, DIO- Mask, DIO-Control, Port 1, and Port 0 to zeros. A write to this register is used to clear the board.

**Port 0 Direction Register:**

Writing a zero to a bit in this register makes the corresponding pin of the aDIO connector an input. Writing a one to a bit in this register makes the corresponding pin of the aDIO connector an output.

**Mask Register:**

Writing a zero to a bit in this register will not mask off the corresponding bit in the DIO-Compare register. Writing a one to a bit in this register masks off the corresponding bit in the DIO-Compare register. When all bits are masked off the aDIOs comparator is disabled. This condition means Event and Match mode will not generate an interrupt. This register is used by Event and Match modes.

**Compare Register:**

A Read/Write register used for Match Mode. Bit values in this register that are not masked off are compared against the value on Port 0. A Match or Event causes bit 6 of DIO-Control to be set and if the aDIO is in Advanced interrupt mode, the Match or Event causes an interrupt.

Port 1 Data register is a read/write byte direction

## Interrupts

In order to use an interrupt with aDIO, the interrupt must first be selected in the BIOS setup utility under **Advanced, RTD Advanced Options, RTD aDIO, aDIO Interrupt**. The Digital I/O can use interrupts 3, 5, 6, 10, and 11. To configure the aDIO interrupt, navigate to the BIOS Setup option, the “Advanced”, “RTD aDIO”, and “aDIO Interrupt” menu options. The BIOS will automatically reserve the selected interrupt so that it is not assigned to PCI devices. Then, select the appropriate interrupt mode in the DIO Control register.

### Advanced Digital Interrupts

There are three Advanced Digital Interrupt modes available. These three modes are Event, Match, and Strobe. The use of these three modes is to monitor state changes at the aDIO connector. Interrupts are enabled by writing to the **Digital IRQ Mode** field in the **DIO-Control** register.

#### Event Mode

When this mode is enabled, Port 0 is latched into the DIO-Compare register. The aDIO circuitry includes deglitching logic. To enter Event mode, set bits [4:3] of the DIO-Control register to “10”.


#### Match Mode

When this mode is enabled, Port 0 is latched into the DIO-Compare register. The aDIO circuitry includes deglitching logic. To enter Match mode, set bits [4:3] of the DIO-Control register to “11”.



**Note** Make sure bits [4:3] are set BEFORE writing the DIO-Compare register. If you do not set them first, the contents of the DIO-Compare register could be lost because the Event mode latches in Port 0 into the DIO-Compare register.

---



**Figure 6 aDIO Match Mode**

### **Strobe Mode**

Another interrupt mode supported by aDIO is Strobe mode. This allows the strobe pin of the DIO connector to trigger an interrupt. A low to high transition on the strobe pin will cause an interrupt request. The request will remain high until the Clear Register is read from. Additionally, the Compare Register latched in the value at Port 0 when the Strobe pin made a low to high transition. No further strobes will be available until a read of the Compare Register is made. You must read the Compare Register, and then clear interrupts so that the latched value in the compare register is not lost. To enter Strobe mode, set bits [4:3] of the DIO-Control register to "01".

# SATA Controller Configuration

The CMX34BT has two SATA links. One SATA link resides on the top PCIe/104 Type 2 connector (**CN1**), and the second SATA link connects to the onboard SATA storage. Both may be enabled or disabled through the BIOS setup.

## SATA Port Mappings, by Connector

Table 41 shows the SATA port configuration of the CMX34BT cpuModule:

**Table 41 SATA Port Layout**

Designator	Physical Position, Index	E3800 Port Index	Channel Assignment (Legacy IDE Mode)
<b>CN1</b>	SATA PCIe link 0	0	Primary Master
<b>n/a</b>	Onboard SATA storage	1	Primary Slave

## Onboard SATA Storage

The cpuModule was designed to be used in embedded computing applications. In such environments, rotating media like hard disks and floppy disks are not very desirable. It is possible to eliminate rotating storage devices by placing your operating system and application software into the cpuModule's onboard SATA storage.

## SATA Links on the PCIe/104 Type Connectors

Both SATA links are connected to the Intel E3800 CPU's SATA controller which can be configured for either AHCI or IDE mode through the BIOS. However, the operating system must support the selected mode for the device to operate correctly. The default configuration for the controller is AHCI mode.

When in IDE mode, the user has an additional option to change the IDE emulation mode to Native Mode or Legacy Mode. When the SATA controller is configured for IDE mode, Native Mode is the default IDE emulation mode.

### Native IDE Mode

Native Mode allows more flexibility than Legacy Mode, as it permits the system to modify the resources used by the SATA controller. When in Native Mode, the SATA controller only requires a single IRQ. Unlike Legacy Mode, this IRQ may be changed by the user or the operating system for better distribution of the system IRQs. When IRQs in the system are more evenly distributed, interrupt latency is minimized. The base address of the controller may also be modified.

### Legacy IDE Mode

When in this mode, the controller will be fixed to use two interrupts: IRQs 14 and 15. Similarly, the I/O address of the controller will be fixed in the system. When in Legacy Mode, only a primary and secondary channel may be used in the system.

# Watchdog Timer Control

The cpuModule includes a Watchdog Timer, which provides protection against programs “hanging”, or getting stuck in an execution loop where they cannot respond correctly. The watchdog timer consists of a counter, a reset generator, and an interrupt generator. When the counter reaches the interrupt time-out, it can generate an interrupt. When the counter reaches the reset time-out, the system is reset. The counter is “refreshed,” or set back to zero by reading from a specific register. The watchdog can also be put into an “inactive” state, in which no resets or interrupts are generated.

The ability to generate an interrupt allows the application to gracefully recover from a bad state. For example, consider a system that has a reset time-out of 2 seconds, interrupt time-out of 1 second, and the watchdog timer is refreshed every 0.5 seconds. If something goes wrong, an interrupt is generated. The Interrupt service routine then attempts to restart the application software. If it is successful, the application is restarted in much less time than a full reboot would require. If it is not successful, the system is rebooted.

Due to system latency, it is recommended that the Watchdog be refreshed at about half of the reset time-out period, or half of the interrupt time-out period, whichever is applicable.

## Register Description

The Advanced Watchdog Timer has a Setup Register and a Runtime Register. The Setup Register is set by the BIOS, and can be adjusted by entering the BIOS Setup Utility, and going to “Advanced”, “RTD Advanced Options”, “RTD Miscellaneous Feature Control”. The Setup Register may also be read by the driver to determine if the Watchdog is enabled, and the interrupt and base address that it is using.



**Note** Enabling the watchdog timer in the BIOS does not actually arm it. The watchdog timer can be armed by accessing I/O address E85h, as explained below.

**Table 42 Advanced Watchdog Setup Register E8Bh**

D7	D6	D5	D4	D3	D2	D1	D0
Reserved			<b>WDT_IRQ</b>			<b>Reg_Enable</b>	
			Select Interrupt for WDT			0 = Watchdog timer is disabled and Runtime Register will not appear in I/O map	
			000 = Disabled			1 = Watchdog Timer is enabled. Runtime Register will appear in I/O map	
			001 = IRQ5				
			010 = Reserved				
			011 = IRQ10				
			100 = IRQ11				
			101 = Reserved				
			110 = IRQ3				
			111 = IRQ6				

**Table 43 Advanced Watchdog Runtime Register E85h**

D7	D6	D5	D4	D3	D2	D1	D0
<b>WDT_Active</b>	<b>WDT_IRQ_Ena</b>	Reserved		<b>WDT_IRQ_Time</b>	<b>WDT_RST_Time</b>		
0 = Watchdog timer is disabled.	0 = Watchdog interrupt is disabled.			Select Interrupt time for WDT	Select Reset time for WDT		
1 = Watchdog is armed and can generate resets and interrupts.	1 = Watchdog interrupt is enabled.			00 = 0.25s	00 = 2.00s		
				01 = 0.50s	01 = 0.50s		
				10 = 0.75s	10 = 0.75s		
				11 = 1.00s	11 = 1.00s		

Reading the Runtime Register also refreshes the watchdog timer.

# Thermal Management

The cpuModule has several thermal features which can be used to monitor and control the board's temperature when extreme operating conditions are prevalent.

## Thermal Warning

The cpuModule includes a Thermal Warning mechanism which will assert a signal when the processor's temperature has reached or exceeded 100 C. At this time, a bit will be set in the reset and event status register to indicate that this temperature has been entered. Although the LED has turned white and a thermal warning bit has been set, the CPU will maintain the current power and operating state.

For more information on the reset status register, refer to *Reset and Event Status Register*— page 68.

## ACPI-Enforced Thermal Protection

When the maximum thermal junction temperature of the processor is reached, the system is at risk of malfunctioning, and the cpuModule may become permanently damaged.

For operating system with ACPI support, the system offers two mechanisms to help prevent the processor from reaching its maximum thermal junction temperature -- the **Critical Trip Point** and the **Passive Trip Point**. Both of these temperatures may be configured in the BIOS Setup.

### Critical Trip Point

The Critical Trip Point controls the temperature at which an ACPI operating system will shut down the system. Upon entering the Critical Trip state, the operating system will issue a command to the processor, and the CMX34BT will immediately transition to the **S5** (Soft-Off) ACPI power state.

To exit the Critical Trip state (and S5), the CPU temperature must be reduced to a point that the internal thermal sensors are below the Critical Trip Point. Next, a power cycle or RSM reset (deepest reset) is required. The reset button may be configured as an RSM reset (default BIOS setting) in the BIOS setup utility.

For more information on the S5 power state, refer to *Advanced Configuration and Power Interface (ACPI)*— page 65.

### Passive Trip Point

The Passive Trip Point controls the temperature at which an ACPI operating system will begin to throttle the processor.

## Further Temperature Reduction

The cpuModule's temperature is directly related to power consumption. Reducing the power consumption of the cpuModule will have an effect on the cpuModule's temperature. Suggested methods for reducing the cpuModule's power consumption can be found in the *Power Management* section on page 65.



# Power Management

The CMX34BT cpuModule supports various powering mechanisms which allow the cpuModule to monitor power consumption and temperature, and achieve minimal power consumption states. These unique features include thermal monitoring and thermal throttling, as well as ACPI low power modes. Various wake options are also available to resume normal system power.

## Advanced Configuration and Power Interface (ACPI)

The cpuModule supports several different ACPI low power modes, including the S3, S4, and S5 sleeping states. These suspend modes are described below:

- **S3 (Suspend to RAM):** When the system wakes from this mode, operating systems allow applications to resume where they left off, as the state of the application is preserved in memory.
- **S4 (Hibernate):** When the system enters this state, the operating system will save the current state of applications and relevant data to disk, thus allowing the system RAM to be powered down.
- **S5 (Soft-Off):** The system is in a soft off state, and must be rebooted when it wakes.

## Power Button Modes

The soft power button input of the Utility Port 2.0 connector (**CN5**) can be configured by the operating system as a suspend button (transition to S3) or as soft power button (transition to S5). Consult your operating system documentation for information on how to configure it. The power button will always cause a transition to S5 if pressed for 4 seconds or longer, without interaction from the operating system.

The soft power button of the Utility Port 2.0 connector (**CN5**) is the only mechanism to wake the system from S4 and S5.



**Note** When the reset button of the Utility Port 2.0 connector is configured as a power button (via the BIOS setup utility), it inherits the ACPI suspend and resume features of the power button.

## Low-Power Wake Options

The cpuModule supports several methods of waking from a low power state.

- **Resume from USB:** Operating systems that support S3 permit waking the system from the USB interfaces. Common USB wake methods include insertion of a USB device, a USB keyboard stroke, or movement from another USB device, such as mouse.
- **Resume on RTC Alarm / Timeout:** The RTC Alarm allows the system to turn on at a certain time every day.

**Table 44 Supported ACPI Resume/Wake Mechanisms**

Resume/Wake Mechanism	S3	S4	S5
Wake from USB	Y	—	—
Wake from RTC Alarm / Timeout	Y	—	—
Power Button Input ( <b>CN5</b> )	Y	Y	Y

## AT vs. ATX Power Supplies

Both AT and ATX power supplies may be used with the CMX34BT cpuModule, however AT power supplies do not provide any standby power to the cpuModule. When an AT power supply is used to power the system, low power modes that require a standby power to wake the system will not be fully supported.

ATX power supplies do provide a standby power, thus allowing the system to utilize all low power modes supported by the hardware. When an ATX supply is used to power the cpuModule, lower power modes can be achieved. During these low power modes, the standby power from the ATX power supply provides power to a small circuit on the CPU, which is used to watch for a system wake event.

## ATX Power Supply Signals

The PCIe/104 Type 2 Bus connectors (**CN1** & **CN2**) provide two ATX style signals., +5V Standby and PSON#. The +5V Standby rail is used to power certain parts of the cpuModule when the main power supply is turned off, i.e. during Suspend-to-RAM (S3), Hibernate (S4), or Soft-Off (S5) power modes. The PSON# signal is an active low open-drain output that signals the power supply to turn on. Use of these signals allows the power consumption to drop to below 1W during standby modes, and still enable any of the wake events.

## Reducing Power Consumption

In addition to the CPU's low power modes, power consumption can further be reduced by making some modifications to the BIOS setup. When the following features are disabled in the BIOS, the CPU's power consumption will decrease:

- **Ethernet**
- **USB Ports**
- **SATA Controller**
- **Serial Ports**
- **Multi-Color LED**

## Multi-Color LED

The CMX34BT has a Multi-Color LED which can be enabled or disabled in the BIOS setup screen. The color of the LED indicates the status of the board, as shown in Table 45.

**Table 45 LED Colors**

Color	Description
Green	Normal Operation
Blue	SATA Activity
Red <sup>1</sup>	cpuModule is in reset
Yellow (Red + Green)	cpuModule is in Standby
White (R+G+B)	cpuModule is approaching thermal limit <sup>2</sup>
Cyan (Blue + Green)	Ethernet Link at 100 Mbps or Bus Stacking Error
Magenta (Blue + Red)	Ethernet Link at 1000 Mbps
Blink	Ethernet Activity

1. If power is applied to the cpuModule while jumper **JPS** is installed, the LED will be red. This does not indicate that the board is in reset
2. The LED will remain White until the system is shut down.

The LED can also be controlled manually by writing to I/O Port EA7h, as shown in Table 46 and Table 47.

**Table 46 Multi-Color LED I/O Address EA5h**

D7	D6	D5	D4	D3	D2	D1	D0
Reserved	Reserved	Reserved	Reserved	Reserved		Multi-Color LED	

The following table lists the color displayed and the value written.

**Table 47 Manual LED Colors**

I/O Port EA7h Value	Color
0x00	Automatic (see Table 45)
0x08	Off (will reduce system power consumption)
0x09	Blue
0x0A	Green
0x0B	Cyan (Green + Blue)
0x0C	Red
0x0D	Magenta (Red + Blue)
0x0E	Yellow (Red + Green)
0x0F	White (Red + Green + Blue)

# Reset and Event Status Register

The cpuModule has several different signals on board which can cause a system reset. If a reset occurs, the reset status register can be used to see which reset (or resets) have been asserted on the cpuModule. These resets may be cleared by the user.

Similar to resets, there are several signals on the cpuModule which indicate that a special event has occurred. These may also be monitored and cleared by the user.

- **Examine Resets and Events:** Reading from I/O ports 0xED0h through 0xED3 will indicate if a reset has been asserted or if an event has occurred. If a 1 is read, the corresponding reset has been asserted. If a 0 is read from the bit, the reset has not been asserted. For events
- **Clear Reset and Event:** Each reset and event can be cleared by writing a 1 to the selected bit of I/O port 0xED0h.

**Table 48 Reset and Event Status I/O Address ED0h - Read Access**

D7	D6	D5	D4	D3	D2	D1	D0
<b>Sleep S4</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.8V Always</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.0V Always</b> 1 = reset asserted 0 = no reset	<b>PwrGood 5V Always</b> 1 = reset asserted 0 = no reset	<b>RSM Reset</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.5V Always</b> 1 = reset asserted 0 = no reset	<b>PwrGood 3.3V Always</b> 1 = reset asserted 0 = no reset	<b>Main 5V Power</b> 1 = reset asserted 0 = no reset

**Table 49 Reset and Event Status I/O Address ED1h - Read Access**

D7	D6	D5	D4	D3	D2	D1	D0
<b>PwrGood 1.05V</b> 1 = reset asserted 0 = no reset	<b>Pwr Good Vcore</b> 1 = reset asserted 0 = no reset	<b>Sleep S3</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.2V Always</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.0V</b> 1 = reset asserted 0 = no reset	<b>PwrGood Vgfx</b> 1 = reset asserted 0 = no reset	<b>PwrGood 1.9V Always</b> 1 = reset asserted 0 = no reset	<b>Memory Pwr Good</b> 1 = reset asserted 0 = no reset

**Table 50 Reset and Event Status I/O Address ED2h - Read Access**

D7	D6	D5	D4	D3	D2	D1	D0
WDT Trip 1 = reset asserted 0 = no reset	Thermal Warning 1 = reset asserted 0 = no reset	Platform Reset 1 = reset asserted 0 = no reset	Reserved	Mem. Term. Voltage 1 = reset asserted 0 = no reset	PwrGood 3.3V 1 = reset asserted 0 = no reset	PwrGood 1.8V 1 = reset asserted 0 = no reset	PwrGood 1.35V 1 = reset asserted 0 = no reset

**Table 51 Reset and Event Status I/O Address ED3h - Read Access**

D7	D6	D5	D4	D3	D2	D1	D0
Reserved	Reserved	ATX Pwr Good 1 = reset asserted 0 = no reset	Reserved	Reserved	Reserved	Soft Power Off 1 = reset asserted 0 = no reset	Utility Reset 1 = reset asserted 0 = no reset
			Bus Stack Error 1 = reset asserted 0 = no reset				

## Features and Settings That Can Affect Boot Time

The boot time of a system is dependent upon numerous system settings as well as devices attached to a system. This section addresses some devices and settings that can increase or decrease a system's boot time.

### Boot Device Order

The BIOS contains a list of devices to try booting from. If you wish to boot to a particular device (for example, a hard drive), make sure that it is first in the boot order. This will speed up boot times.

### Add-On Cards With BIOS Extensions

Some add-on cards have an integrated BIOS extension. The most common examples are SCSI controllers and network cards with boot ROMs. During POST, the BIOS executes the card's extension code. This extension code is third-party code, which is beyond RTD's control. The BIOS extension will most likely increase the boot time. Exactly how much it increases boot time will depend on the particular card and firmware version.

### VGA Controller

VGA controllers have a VGA BIOS that must be initialized during POST. It can take some time to initialize the VGA BIOS. Exactly how long will depend on the particular VGA controller and BIOS version.

### Hard Drive Type

During Hard Drive initialization, each device must be probed. Some devices take longer to probe. 2.5-inch hard drives tend to take longer than 3.5-inch ones, because they spin at a lower RPM.

### Monitor Type

Some monitors take a while to power on. Desktop flat panels are especially slow. This does not affect the actual boot time of the CPU. However, the CPU may boot before the monitor powers on.

# System Recovery

## Reset Button Recovery

The CMX34BT provides several methods for recovering from an incorrectly configured system. In order to enter the recovery mode, follow the steps below:

1. Remove power from the system, including standby power.
2. Press and hold the reset button attached to the Utility Port 2.0 connector.
3. Apply power to the system while continuing to hold the reset button.
4. Wait the amount of time shown in Table 52 for the desired recovery mode.
5. Release the reset button, allowing the system to boot.

**Table 52 Reset Button Recovery Modes**

Hold Time <sup>1</sup>	Mode
0-4 seconds	No recovery mode. System will stay in reset while button is pressed.
4-8 seconds	Load Default BIOS Settings
8-12 seconds	Serial POST Code Output

1. To assist with timing while the reset button is pushed, the LED will blink OFF at 5 second intervals.

## Load Default BIOS Settings

Loading BIOS defaults allows recovery from an incorrectly configured display device, incorrect boot options, and many other incorrect settings. It is also a good starting point when making BIOS changes. After restoring defaults, the BIOS settings should be reviewed and modified as needed.

The default BIOS can be restored either by using Reset Button Recovery, or the “Load RTD Defaults” option in the BIOS.

## Serial Power-On-Self-Test (POST) Code Output

The POST Codes represent a series of events that take place in a system during the Power On Self Test. If the POST fails, the system will not boot as expected. Knowing which POST code the failure occurred may help system debug.

This recovery mode configures serial port connector **CN7** as single RS-232, and sends the POST codes on the transmit pin. The port settings are 115kbps, 8 bits, no parity, one stop bit. When using this recovery mode, the POST codes can be logged on another computer running terminal software. Contact RTD technical support for more details.



**Note** POST Codes over the serial port (**CN7**) may also be enabled by installing **JP5** and **JP6** prior to power cycling the *cpuModule*. For more information, see *Jumper Settings and Locations* on page 74.







## Appendix A Hardware Reference

This appendix provides information on CMX34BT cpuModule hardware, including:

*Jumper Settings and Locations* — page 74

*Onboard PCI/PCIe Devices* — page 75

*Physical Dimensions* — page 76


*Heatsink Dimensions* — page 77

*Flat-Heatspreader Dimensions* — page 79

## Jumper Settings and Locations

Many cpuModule options are configured by positioning jumpers. Jumpers are labeled on the board as **JP** followed by a number.

Figure 7 shows the jumper locations that are used to configure the cpuModule. Table 53 lists the jumpers and their settings.



**Figure 7 CMX34BT Jumper Locations (top side)**

**Table 53 CMX34BT Jumpers**

Jumper	Pins	Function	Default
<b>JP5</b>	2	Reserved	open
<b>JP6</b>	2	Reserved	open
<b>JP5 + JP6</b>	2	Used to configure serial port connector <b>CN7</b> as single RS-232, and sends the POST codes on the transmit pin. See <i>Serial Power-On-Self-Test (POST) Code Output</i> on page 71 <b>pins 1–2 (JP5 and JP6):</b> Enable POST Codes over Serial Port <b>CN7</b> <b>open:</b> Normal operation	open

## Onboard PCI/PCIe Devices

The CMX34BT cpuModule has several onboard PCI/PCIe devices, all of which are listed in the table below. This table shows a typical configuration, and the actual devices may change based on BIOS settings.

**Table 54 Onboard PCI/PCIe Devices**


Device ID	Vendor ID	Description
0F00	8086	Host bridge
0F04	8086	HD Audio Controller
0F31	8086	Video Controller
0F23	8086	SATA Controller (AHCI Mode) <sup>1</sup>
0F18	8086	Intel TXE (Trusted Execution Engine)
0F48	8086	PCI Express Root Port 1
0F4A	8086	PCI Express Root Port 2
0F4C	8086	PCI Express Root Port 3
0F4E	8086	PCI Express Root Port 4
0F34	8086	USB Controller (EHCI)
0F1C	8086	Platform Controller Unit - LPC Bridge
0F12	8086	Platform Controller Unit - SMBus Port
8605	10B5	PCI Express Packet Switch <sup>2</sup>
8112	10B5	PCI Express to PCI Bridge
10D3	8086	Ethernet Controller - Intel 82574 Series ( <b>CN20</b> )
10D3	8086	Ethernet Controller - Intel 82574 Series ( <b>CN30</b> )

1.Can change if the BIOS is configured for IDE mode instead of AHCI.

2.This device may appear up to five times in PCI configuration space, depending on how many PCIe links are active.

# Physical Dimensions

Figure 8 shows the mechanical dimensions of the CMX34BT cpuModule.




**Figure 8 CMX34BT Physical Dimensions ( $\pm 0.005$  inches)**

## Heatsink Dimensions


To maximize the thermal performance of the cpuModule while keeping the total board weight to a minimum, various heatsinks are offered with each ordering part number. Use the table below to correlate the heatsink figure to each ordering part number.

**Table 55 CMX34BT cpuModule Model Options**

Part Number	Core Frequency	Stack Height	Heatsink
CMX34BTS1460HR-4096/S32GX	1.46 GHz	0.600" (15.24mm)	Figure 9
CMX34BTD1330HR-4096/S32GX	1.33 GHz	0.600" (15.24mm)	Figure 10
CMX34BTQ1910HR-4096/S32GX	1.91 GHz	0.866" (22mm)	Figure 11




**Figure 9 CMX34BTS1460 Heatsink**



**Figure 10 CMX34BTD1330 Heatsink**

Edge near  
PCIe/104 Connector



**Figure 11** CMX34BTQ1910 Heatsink


# Flat-Heatspreader Dimensions

For cooling solutions where it is desirable to mount the cpuModule to a flat surface, the CMX34BT may be ordered with a flat heatspreader instead of the standard passive heatsink. Each flat-heatspreader has five mounting locations which use Heli-Coil coils, 6-32 UNC.


Use the table below to correlate the heatsink figure to each ordering part number.

**Table 56 CMX34BT cpuModule Model Options**

Part Number	Core Frequency	Stack Height	Heatspreader
CMX34BTS1460HR-4096/S32GXF	1.46 GHz	0.600" (15.24mm)	Figure 12
CMX34BTD1330HR-4096/S32GXF	1.33 GHz	0.600" (15.24mm)	Figure 12
CMX34BTQ1910HR-4096/S32GXF	1.91 GHz	0.866" (22mm)	Figure 13



**Figure 12 0.600" (15.24mm) Flat-Heatspreader**



**Figure 13 0.866" (22mm) Flat-Heatspreader**







## Appendix B Troubleshooting

Many problems you may encounter with operation of your CMX34BT cpuModule are due to common errors. This appendix includes the following sections to help you get your system operating properly.

*Common Problems and Solutions* — page 82

*Troubleshooting a PC/104 System* — page 83

*How to Obtain Technical Support* — page 84

## Common Problems and Solutions

Table 57 lists some of the common problems you may encounter while using your CMX34BT cpuModule, and suggests possible solutions.

If you are having problems with your cpuModule, review this table before contacting RTD Technical Support.

**Table 57 Troubleshooting**

Problem	Additional Symptoms	Possible Cause(s)
cpuModule does not boot (no video output)	LED is red (in reset)	Input power is inadequate. Refer to Chapter 1, <i>Electrical Characteristics</i> . Verify input voltages are correct. If power is supplied via <b>CN3</b> , check for cabling issues.  Malfunctioning peripheral card. Remove all peripheral cards from the system.
	LED is yellow (in standby)	cpuModule is in "Soft Off" due to operating system shutdown. Press power button to wake.  ATX power supply is not turning on. Check jumpers on power supply. Verify PSON# signal.
	LED is cyan (bus stacking error)	See Chapter 3, <i>PCIe/104 Type 2 Compatibility</i>
	LED is green (normal operation)	cpuModule may be booted, but video is not connected properly. Attach a keyboard and verify the operation of the Num Lock and Caps Lock LEDs. If they respond as expected, the cpuModule is booted. Check the video cable connections.  Video output may have been disabled in the BIOS. Try loading BIOS defaults per Chapter 4, <i>System Recovery</i> .  If a PCI device is installed, the slot selection switch/jumpers may not be set correctly.  Peripheral card may be interfering with boot sequence. Remove all peripheral cards from the system.
cpuModule reboots unexpectedly	cpuModule is running Windows	By default, Windows will automatically reboot when a Bugcheck (Blue Screen) is triggered. Disable this feature in the Control Panel. This will allow you to see the error and identify the root cause.
	cpuModule is powered via Auxiliary Power Connector ( <b>CN3</b> )	Power cabling issues. Verify all pins on <b>CN3</b> are reliably connected with proper gauge wires.  Power supply noise or current limiting. Check power pins with an oscilloscope and verify they remain in range.  Power supply may not respond quickly enough to changes in power consumption. Switch to a different power supply (a PCI Express power supply is recommended)
	Peripheral card(s) installed	Peripheral card(s) may be overloading the power supply. Reduce the system to just the cpuModule and power supply and see if the problem re-appears. (Note that <b>CN3</b> is intended for powering the cpuModule only.)
cpuModule does not boot to USB device	USB device has a high power draw (e.g. DVD or hard drive)	Some USB devices are not fully compliant and draw too much current. Consider switching to a self-powered USB device with its own AC/DC power supply.
Date/time not saved when system is off	No RTC battery	A battery must be attached to the Utility Port 2.0 connector ( <b>CN5</b> ) to maintain date/time when main power is removed. For a list of alternate battery inputs, refer to <i>Watchdog Timer Control</i> — page 63.
System performance lower than expected	LED is white	cpuModule is overheating and the processor is throttling. Increase the cooling (more airflow, larger heatsink, etc).

## Troubleshooting a PC/104 System

If you have reviewed the preceding table and still cannot isolate the problem with your CMX34BT cpuModule, please try the following troubleshooting steps. Even if the resulting information does not help you find the problem, it will be very helpful if you need to contact technical support.

1. **Simplify the system.** Remove items one at a time and see if one particular item seems to cause the problem.
2. **Swap components.** Try replacing items in the system one-at-a-time with similar items.

## How to Obtain Technical Support

If after following the above steps, you still cannot resolve a problem with your CMX34BT cpuModule, please gather the following information:

- cpuModule model, BIOS version, and serial number
- List of all boards in system
- List of settings from cpuModule Setup program
- Printout of autoexec.bat and config.sys files (if applicable)
- Description of problem
- Circumstances under which problem occurs

Then contact RTD Technical Support:

Phone: 814-234-8087

Fax: 814-234-5218


E-mail: [techsupport@rtd.com](mailto:techsupport@rtd.com)

## Appendix C IDAN™ Dimensions and Pinout

Like all other RTD PC/PCI-104 and PCIe/104 modules, cpuModules can be packaged in Intelligent Data Acquisition Node (IDAN) frames, which are milled aluminum frames with integrated heat sinks and heat pipes for fanless operation. RTD modules installed in IDAN frames are called building blocks. IDAN building blocks maintain the simple but rugged stacking concept of PC/PCI-104 and PCIe/104. Each RTD module is mounted in its own IDAN frame and all I/O connections are brought to the walls of each frame using standard PC connectors.


On the CMX34BT, no connections are made from module to module internal to the system other than through the PCIe/104 Type 2 bus, enabling quick interchangeability and system expansion without hours of rewiring and board redesign.

The CMX34BT cpuModule can also be purchased as part of a custom-built RTD HiDAN™ or HiDANplus™ High Reliability Intelligent Data Acquisition Node. This appendix provides the dimensions and pinouts of the CMX34BT installed in an IDAN frame. Contact RTD for more information on high reliability IDAN, HiDAN, and HiDANplus PC/PCI-104 systems.



**IDAN**—Adhering to the PC/PCI-104 and PCIe/104 stacking concept, IDAN allows you to build a customized system with any combination of RTD modules.

**IDAN Heat Pipes**—Advanced heat pipe technology maximizes heat transfer to heat sink fins.



**HiDANplus**—Integrating the modularity of IDAN with the ruggedization of HiDAN, HiDANplus enables connectors on all system frames, with signals running between frames through a dedicated stack-through raceway.



## IDAN Contents

The IDAN-CMX34BT contains both a CMX34BT cpuModule and a **SATA34106** storage module which provides a 2.5" SATA interface to the first SATA link on the CPU's top PCIe/104 Type 2 connector (**CN1**).

Also inside the IDAN-CMX34BT unit is a CMOS battery which is connected to the battery input connection of the cpuModule's Utility Port 2.0 connector. The frame of the IDAN-CMX34BT brings out the cpuModule's multi-color LED as well as the cpuModule's reset button. While a power button is not provided on the exterior of the frame, the reset button is configurable as a power button through the BIOS Setup utility.

For additional flexibility, the 25-pin "D" connector which provides connections to the cpuModule's aDIO connector (**CN6**) includes connections to several pins on the Utility Port 2.0 connector, which include the reset button input, power button input, and RTC battery input.

For more information on cpuModule's battery input and reset button input on the Utility Port 2.0 connector, refer to the *Utility Port 2.0 Connector (CN5)* on page 31.

## IDAN Dimensions

The IDAN frame for the CMX34BT is shown in the figure below:






Figure 14 IDAN-CMX34BT

# IDAN Connector Locations

The diagrams below show the connector locations for the headers of the CMX34BT as they are brought out on the front and back panels of the IDAN-CMX34BT. For a full description of each connector on the CMX34BT, refer to *Connecting the cpuModule* on page 27.



**Figure 15 IDAN-CMX34BT Front Panel**



**Figure 16 IDAN-CMX34BT Back Panel**

**Table 58 IDAN-CMX34BT Connectors**

<b>Designator</b>	<b>Function</b>	<b>Connector Description</b>	<b>IDAN Panel Connector</b>	<b>Mating Connector</b>
<b>CN5</b>	USB Port (Utility Port 2.0)	USB Type A	Series "A" Receptacle	Series "A" Plug
<b>CN6</b>	aDIO	25-pin D (female)	Adam Tech DB25SD	Adam Tech DB25PD
<b>CN7</b>	Serial Port 1 (COM1&3)	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD
<b>CN8</b>	Serial Port 2 (COM2&4)	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD
<b>CN17</b>	USB 2.0	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD
<b>CN18</b>	Video (SVGA)	15-pin high-density D (female)	Adam Tech HDT15SD	Adam Tech HDT15PD
<b>CN19</b>	DisplayPort	DisplayPort (female)	Molex 47272 series	Molex 68783 series
<b>CN20</b>	Ethernet	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD
<b>CN27</b>	USB 2.0	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD
<b>CN30</b>	Ethernet	9-pin D (male)	Adam Tech DE09PD	Adam Tech DE09SD



## External I/O Connections

**Table 59 COM1/COM2 (Single Port Mode)— 9-Pin D Connector (male)**

CPU Pin	IDAN Pin (DB-9)	Single RS-232	Single RS-422	Single RS-485
1	1	DCD	TXD-	D-
2	6	DSR	—	—
3	2	RXD	TXD+	D+
4	7	RTS	—	—
5	3	TXD	RXD+	—
6	8	CTS	—	—
7	4	DTR	RXD-	—
8	9	RI	—	—
9	5	GND	GND	GND

**Table 60 COM1/COM2 (Dual Port Mode)— 9-Pin D Connector (male)**

CPU Pin	IDAN Pin (DB-9)	Dual RS-232	Dual RS-422	Dual RS-485
1	1	DCD1	TXD1-	D1-
3	2	RXD1	TXD1+	D1+
5	3	TXD1	RXD1+	—
7	4	RTS1	RXD1-	—
9	5	GND	GND	GND
2	6	CTS1	TXD2-	D2-
4	7	TXD2	TXD2+	D2+
6	8	RXD2	RXD2+	—
8	9	RI1	RXD2-	—

**Table 61 aDIO — 25-Pin D Connector (female)**

IDAN Pin #	aDIO Port	CPU Pin # (CN6)	CPU Pin # (CN5)
1	P0-0	1	—
2	P0-2	3	—
3	P0-4	5	—
4	P0-6	7	—
5	Strobe 0	9	—
6	P1-0	11	—
7	P1-2	13	—
8	GND	15	—

**Table 61 aDIO — 25-Pin D Connector (female)**

IDAN Pin #	aDIO Port	CPU Pin # (CN6)	CPU Pin # (CN5)
9	reserved	—	—
10	reserved	—	—
11	reserved	—	—
12	Soft Power Button Input	—	5
13	GND (for RTC Battery Input)	—	7
14	P0-1	2	—
15	P0-3	4	—
16	P0-5	6	—
17	P0-7	8	—
18	Strobe 1	10	—
19	P1-1	12	—
20	P1-3	14	—
21	+5 V	16	—
22	reserved	—	—
23	reserved	—	—
24	Push-Button Reset Input	—	3
25	RTC Battery Input	—	9

**Table 62 SVGA — 15-Pin High Density D Connector (female)**

IDAN Pin #	Signal	Function	CPU Pin #
1	Red	Red Analog Output	4
2	Green	Green Analog Output	6
3	Blue	Blue Analog Output	8
4	Reserved	Reserved	—
5	GND	Ground	9
6	GND	Ground	9
7	GND	Ground	9
8	GND	Ground	10
9	+5 V	+ 5 Volts	7
10	GND	Ground	10
11	Reserved	Reserved	—
12	DDC Data	Monitor data	5
13	HSYNC	Horizontal Sync	2
14	VSYNC	Vertical Sync	1
15	DDC CLK	Monitor Clock	3

**Table 63 DisplayPort Connector**

Pin	Signal	Standard Function	DVI / HDMI mode <sup>1</sup>	In/Out
1	LN0+	Main Link, Lane 0 (positive)	TMDS Channel 2 (positive)	out
2	GND	Ground	Ground	out
3	LN0-	Main Link, Lane 0 (negative)	TMDS Channel 2 (negative)	out
4	LN1+	Main Link, Lane 1 (positive)	TMDS Channel 1 (positive)	out
5	GND	Ground	Ground	out
6	LN1-	Main Link, Lane 1 (negative)	TMDS Channel 1 (negative)	out
7	LN2+	Main Link, Lane 2 (positive)	TMDS Channel 0 (positive)	out
8	GND	Ground	Ground	out
9	LN2-	Main Link, Lane 2 (negative)	TMDS Channel 0 (negative)	out
10	LN3+	Main Link, Lane 3 (positive)	TMDS Clock (positive)	out
11	GND	Ground	Ground	out
12	LN3-	Main Link, Lane 3 (negative)	TMDS Clock (negative)	out
13	CFG1	Configuration Pin 1	Cable Adapter Detect	out
14	CFG2	Configuration Pin 2	Consumer Electronics Control <sup>2</sup>	out
15	AUX+	Auxiliary Channel (positive)	DDC Clock	in/out
16	GND	Ground	Ground	out
17	AUX-	Auxiliary Channel (negative)	DDC Data	in/out
18	HPD	Hot Plug Detect	Hot Plug Detect	in
19	DPG	Return for DPV	Return for DPV	out
20	DPV	+3.3V DC Power	+3.3V DC Power	out

1.Requires special passive adapter

2.HDMI mode only

Facing DisplayPort connector, the pinout is:

19	17	15	13	11	9	7	5	3	1
DPG	AUX-	AUX+	CFG1	GND	LN2-	LN2+	GND	LN0-	LN0+
DPV	HPD	GND	CFG2	LN3-	LN3+	GND	LN1-	LN1+	GND
20	18	16	14	12	10	8	6	4	2

**Table 64 USB — 9-Pin D Connector (male)**

IDAN Pin #	Signal	Function	Mode	CPU Pin #
1	VCC1	+5 V to USB1	output	1
2	Data USB1-	USB1 Data-	input/output	3
3	Data USB1+	USB1 Data+	input/output	5
4	GND	Ground	—	7
5	Shield GND	Shield Ground	—	9
6	VCC2	+5 V to USB2	output	2
7	Data USB2-	USB2 Data-	input/output	4
8	Data USB2+	USB2 Data+	input/output	6
9	GND	Ground	—	8

**Table 65 Ethernet — 9-Pin D Connector (male)**

IDAN Pin #	RJ-45 Pin	Signal	CPU Pin #
1	3	B+ (RX+)	1
2	4	C+	3
3	1	A+ (TX+)	5
4	7	D+	7
5	—	Ground	9
6	6	B- (RX-)	2
7	5	C-	4
8	2	A- (TX-)	6
9	8	D-	8





## Appendix D Additional Information

### Application Notes

RTD offers many application notes that provide assistance with the unique feature set of the CMX34BT cpuModule. For the latest application notes, refer to the RTD website.

### Drivers and Example Programs

To obtain the latest versions of drivers and example programs for this cpuModule, refer to the RTD website.

### Interrupt Programming

For more information about interrupts and writing interrupt service routines, refer to the following book:

Interrupt-Driven PC System Design  
by Joseph McGivern  
ISBN: 0929392507

### Serial Port Programming

For more information about programming serial port UARTs, consult the following book:

Serial Communications Developer's Guide  
by Mark Nielson  
ISBN: 0764545701

### PC/104 Specifications

A copy of the latest PC/104 specifications can be found on the webpage for the PC/104 Embedded Consortium:

<http://www.pc104.org>







## Appendix E Limited Warranty

RTD Embedded Technologies, Inc. warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from RTD Embedded Technologies, Inc. This warranty is limited to the original purchaser of product and is not transferable.

During the one year warranty period, RTD Embedded Technologies will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to RTD Embedded Technologies. All replaced parts and products become the property of RTD Embedded Technologies. Before returning any product for repair, customers are required to contact the factory for a Return Material Authorization number.

This limited warranty does not extend to any products which have been damaged as a result of accident, misuse, abuse (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by RTD Embedded Technologies, "acts of god" or other contingencies beyond the control of RTD Embedded Technologies), or as a result of service or modification by anyone other than RTD Embedded Technologies. Except as expressly set forth above, no other warranties are expressed or implied, including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose, and RTD Embedded Technologies expressly disclaims all warranties not stated herein. All implied warranties, including implied warranties for merchantability and fitness for a particular purpose, are limited to the duration of this warranty. In the event the product is not free from defects as warranted above, the purchaser's sole remedy shall be repair or replacement as provided above. Under no circumstances will RTD Embedded Technologies be liable to the purchaser or any user for any damages, including any incidental or consequential damages, expenses, lost profits, lost savings, or other damages arising out of the use or inability to use the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, and some states do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RTD Embedded Technologies, Inc.  
103 Innovation Blvd.  
State College PA 16803-0906  
USA  
Website: [www.rtd.com](http://www.rtd.com)

