

IDAN-RSATA-SYS104

SATA Drive Carrier



User's Manual

BDM-610020081 Revision B



www.rtd.com

ISO9001 and AS9100 Certified

rtd[®]
"Accessing the Analog World"

SATA Drive Carrier User's Manual

RTD Document Number: BDM-610020081 Revision B

Copyright © 2012 RTD Embedded Technologies, Inc. All rights reserved.

Trademarks

Advanced Digital I/O, aDIO, a2DIO, Autonomous SmartCal, cpuModule, dspFramework, dspModule, IDAN, HiDAN, HiDAN*plus*, "MIL Value for COTS prices", multiPort, and PC/104EZ are trademarks, and "Accessing the Analog World", dataModule, RTD, and the RTD logo are registered trademarks of RTD Embedded Technologies, Inc. PS/2, PC/XT, PC/AT, and IBM are trademarks of International Business Machines Inc. MS-DOS, Windows, Windows 95, Windows 98, and Windows NT are trademarks of Microsoft Corp. PC/104 is a registered trademark of PC/104 Consortium. All other trademarks appearing in this document are the property of their respective owners.

Contents and specifications within this manual are subject to change without notice.

Revision History

Revision	Date	Reason for Change
A	5/26/10	Initial Release
B	10/4/12	Changed bus name to PCIe/104 Type 2

IDAN-RSATA-SYS104

SATA Drive Carrier



Contact Information

RTD Embedded Technologies, Inc.
103 Innovation Blvd.
State College, PA 16803-0906
USA

Phone: +1-814-234-8087

Fax: +1-814-234-5218

E-mail: sales@rtd.com
techsupport@rtd.com

Internet: <http://www.rtd.com>

Table of Contents

Chapter 1 Introduction

RSATA34106 SATA Drive Carriers	8
Ordering Information	9
Stand Alone Models	9
IDAN Models	9
SATA Drive Carrier Accessories	9
Features	10
Specifications	10
Connectors	10
Operating Temperature Range	10
For More Information	11

Chapter 2 Connecting the SATA Drive Carrier

Installation Considerations	14
Proper Grounding Techniques	14
SATA Drive Carrier Installation	14
RSATA34106 Connector Locations	15
PCIe/104 Type 2 Bus (CN1 & CN2)	16
PCIe/104 Type 2 Compatibility	16
Pin Connections	16
2.5" SATA Drive Connector (CN3)	20
SATA Link Shifting	20

Appendix 1 IDAN™ Dimensions and Pinout

IDAN-RSATA-SYS104	22
Removable Drawer	23
Dimensional Drawing	23

Appendix 2 Limited Warranty



Chapter 1 Introduction

This manual provides comprehensive hardware information on the IDAN-RSATA-SYS104 and RSATA34106.

This manual is organized as follows:

Chapter 1	<i>Introduction</i> introduces product variations and their main features and specifications
Chapter 2	<i>Connecting the SATA Drive Carrier</i> provides information on installing the SATA drive carrier in a system
Appendix 1	<i>IDAN™ Dimensions and Pinout</i> provides connector pinouts and locations for variations of SATA drive carriers installed in an RTD Intelligent Data Acquisition Node (IDAN™) frame
Appendix 2	<i>Limited Warranty</i>

RSATA34106 SATA Drive Carriers

The RSATA34106 SATA drive carrier modules provide a mechanism to utilize the SATA links on the PCIe/104 Type 2 bus connector on select RTD's PCI Express cpuModules. The onboard drive utilizes the first SATA link on the connector, while the other SATA link is lane-shifted up the stack, to permit stacking multiple SATA drive carrier modules within one system.

The RSATA34106 drive carrier provides power to the SATA drive, sourcing the power from the cpuModule's onboard connector, and thus eliminates the need for external out-of-stack cabling.

This manual provides instructions on how to install a 2.5" SATA drive in the removable drawer of the IDAN-RSATA-SYS104, and how to install the IDAN-RSATA-SYS104 into a PCI/104-Express or PCIe/104 system. It will help you get the SATA drive carrier module up and running quickly, and will also provide enough detail about the board and its functions so you can get maximum use of its features in the most demanding applications.




Figure 1 IDAN-RSATA-SYS104 with RSATA34106 SATA Drive Carrier (top view)

Ordering Information

There are several versions of the SATA drive carrier module, some of which are designed for specific usage in an IDAN frame.

Stand Alone Models

The base design variant, intended for use without an RTD system enclosure, may be ordered with the following model number:

- **SATA34106:** 2.5" SATA drive carrier for use with a standalone cpuModule

IDAN Models

The SATA drive carrier can be purchased as part of an Intelligent Data Acquisition Node (IDAN™) building block, which consists of the SATA Drive Carrier module, and a milled aluminum IDAN frame. The IDAN building block can be used in just about any combination with other IDAN building blocks to create a simple but rugged PCI/104-Express or PCIe/104 stack. (for more information refer to Appendix 1).

Design variants of the SATA drive carrier module installed in an IDAN frame can be ordered with the following model numbers:

- **IDAN-SATA34106HRS:** 2.5" SATA drive carrier for use in an IDAN system
- **IDAN-RSATA-SYS104:** 2.5" SATA drive carrier with removable-drive access for use in an IDAN system

The SATA drive carrier can also be purchased as part of a custom-built RTD HiDAN™ or HiDAN*plus* High Reliability Intelligent Data Acquisition Node. Contact RTD for more information on its high reliability PC/PCI-104, PCI/104-Express, and PCIe/104 systems.

Each IDAN-RSATA-SYS104 SATA drive carrier module package contains the following items:

- RSATA34106 SATA drive carrier module
- Machined aluminum frame
- Removable drawer to permit easy removal of data from system
- Companion CD containing documentation

SATA Drive Carrier Accessories

In addition to the items included in your SATA drive carrier module package, several hardware accessories are available, including IDAN frame cable harnesses. Contact RTD or your distributor, or visit the RTD website at www.rtd.com, for more information and for advice on selecting the most appropriate application software and drivers and hardware accessories to support your control system.

Part Number	Description
IDAN-RSATA-DRAWER	Removable SATA Drawer for use with 2.5" SATA Drives

Features

Some of the key features of theIDAN-RSATA-SYS104 SATA drive carrier include:

- Adds one 2.5" SATA (Serial ATA) drive to a system using the PCIe/104 Type 2 bus interface on select RTD cpuModules
 - Removable drawer carrier permits easy removal of data from the system
 - Stack up to 2x SATA drive carrier modules in one system
 - Useful for RAID configurations
- Benefits of SATA over PATA (Parallel ATA)
 - Transfer rates up to 3.0 Gbits per second is faster and more efficient than PATA
 - Dedicated SATA links for each drive in the system eliminate master/slave addressing jumpers
 - Backwards compatibility with PATA permits use of Legacy Mode
- Stackable PCIe/104 Type 2 Expansion Bus
 - Permits system expandability by passing unused SATA links, PCI-Express links, and USB ports from the cpuModule to the next expansion module in the system
- Physical and environmental characteristics
 - Supports 2.5" SATA rotating or flash drives
 - -40 to +85°C operating temperature¹
 - RTD IDAN™ compatible (see Appendix 1, IDAN™ *Dimensions and Pinout*)

Specifications

Connectors

- | | |
|-----------------------|--------------------------------------|
| • PCIe/104 Type 2 Bus | 156-pin Surface Mount (Top & Bottom) |
| • SATA Connector | 2.5" SATA drive |

Operating Temperature Range

Standard	-40 to +85°C
----------	--------------

1. Operating temperature range may be limited by the rating of the SATA drive installed in the SATA drive carrier module

For More Information

Contact RTD if you need further assistance.

RTD Embedded Technologies, Inc.
103 Innovation Blvd.
State College, PA 16803-0906
USA

Phone: +1-814-234-8087
Fax: +1-814-234-5218

E-mail: techsupport@rtd.com
sales@rtd.com

Internet: <http://www.rtd.com>



Chapter 2 Connecting the SATA Drive Carrier

The RSATA34106 SATA drive carrier module interfaces easily to PCI/104-Express and PCIe/104 systems via the PCIe/104 Type 2 bus connector. This chapter provides general installation guidelines for the RSATA34106 as well as information on all connectors.

Installation Considerations — page 14

Proper Grounding Techniques — page 14

SATA Drive Carrier Installation — page 14

RSATA34106 Connector Locations — page 15

PCIe/104 Type 2 Bus (CN1 & CN2) — page 16

2.5" SATA Drive Connector (CN3) — page 20

Installation Considerations

The RSATA34106 is a module with an PCIe/104 Type 2 bus. Therefore, the RSATA34106 should only be installed on a cpuModule which has an PCIe/104 Type 2 bus connector.



CAUTION The PCIe/104 Type 2 connector is the same physical connector as the PCIe/104 Type 1 connector, but has a different pinout. Though it is physically possible to connect the RSATA34106 directly to a PCIe/104 Type 1 bus, doing so could harm the module and other boards in the system.

Proper Grounding Techniques

Before removing the RSATA34106 from its static bag, proper grounding techniques must be used to prevent electrostatic discharge (ESD) damage to the module. Common grounding procedures include an anti-static mat on a workbench, which may connect to an anti-static wrist strap (also known as an ESD wrist strap) on the wrist of the technician or engineer.

SATA Drive Carrier Installation

1. Turn off power to your PCI/104-Express or PCIe/104 system and unplug the cord.
2. Ground yourself with an anti-static strap.
3. Line up the pins of the RSATA34106's bottom side connector with the PCIe/104 Type 2 bus of the stack and gently press the module onto the stack.



CAUTION The RSATA34106 should slide into the connectors on the matching PCI/104-Express or PCIe/104 system easily. Do not force the connection. Doing so might damage pins on the connectors.

4. If any modules are to be installed on the PCIe/104 Type 2 bus above the RSATA34106, install them.
5. Attach any necessary cables to the stack.
6. Reconnect the power cord and apply power to the stack.
7. Boot the system and verify that all of the hardware is working properly.

RSATA34106 Connector Locations

Figure 2 shows the connectors of the SATA driver carrier module.




Figure 2 RSATA34106 Connector Locations



Note Pin 1 of the PCIe/104 Type 2 bus connectors is indicated by a silk screen border at the corner of each connector on the top and bottom of the board. Pin 1 of each connector matches when stacking with other PCIe/104 Type 2 modules.

Table 1 RSATA34106 Connectors

Connector	Function	Size
CN1	PCIe/104 Type 2 Bus (top)	156-pin
CN2	PCIe/104 Type 2 Bus (bottom)	156-pin
CN3	2.5" SATA Drive Connector	7-pin (data segment), 14-pin (power segment)

PCIe/104 Type 2 Bus (CN1 & CN2)

PCIe/104 Type 2 Compatibility

The PCIe/104 Type 2 bus is compatible with any PCI/104-Express or PCIe/104 peripheral module that does not use the x16 Link. This includes any card that uses the PCIe x1 links, USB, or a power supply.

Pin Connections

The signals on the first bank match definitions found in the PCI/104-Express & PCIe/104 Specification Version 1.1 from the PC/104 Embedded Consortium. The signals on the second and third bank are used for SATA hard drive carrier expansion. Table 2 lists the pinout of the PCIe/104 Type 2 bus connector.

Connector **CN1** on the bottom side of the RSATA34106 is the source for the signals of the cpuModule's PCIe/104 Type 2 bus. The only connections on the top-side PCIe/104 Type 2 bus connector (**CN1**) that are not directly passed through from the bottom-side connector (**CN2**) are the SATA links. Other unused features on the bus that are provided by the cpuModule are passed through the RSATA34106's bus connector to the next peripheral module in the stack.

For details on how the SATA links are utilized and passed through the RSATA34106, refer to *SATA Link Shifting* — page 20.



Note Pin 1 of the PCIe/104 Type 2 bus connectors is indicated by a silk screen border at the corner of each connector on the top and bottom of the board.

Table 2 PCIe/104 Type 2 Bus Signal Assignments¹

Pin	Signal	Signal	Pin
1	Pass-through	Pass-through	2
3	+3.3V	+3.3V	4
5	Pass-through	Pass-through	6
7	Pass-through	Pass-through	8
9	GND	GND	10
11	Pass-through	Pass-through	12
13	Pass-through	Pass-through	14
15	GND	GND	16
17	Pass-through	Pass-through	18
19	Pass-through	Pass-through	20
21	GND	GND	22
23	Pass-through	Pass-through	24
25	Pass-through	Pass-through	26
27	GND	GND	28
29	Pass-through	Pass-through	30
31	Pass-through	Pass-through	32
33	GND	GND	34
35	Pass-through	Pass-through	36
37	Pass-through	Pass-through	38
39	Pass-through	Pass-through	40
41	Pass-through	Pass-through	42
43	Pass-through	Pass-through	44
45	CPU_DIR	Pass-through	46
47	Pass-through	Pass-through	48
49	Pass-through	Pass-through	50
51	Pass-through	Pass-through	52

+5 Volts

Table 2 PCIe/104 Type 2 Bus Signal Assignments¹

Pin	Signal	Signal	Pin
53	Reserved	<i>Pass-through</i>	54
55	GND	GND	56
57	<i>Pass-through</i>	<i>Pass-through</i>	58
59	<i>Pass-through</i>	<i>Pass-through</i>	60
61	GND	GND	62
63	<i>Pass-through</i>	<i>Pass-through</i>	64
65	<i>Pass-through</i>	<i>Pass-through</i>	66
67	GND	GND	68
69	<i>Pass-through</i>	<i>Pass-through</i>	70
71	<i>Pass-through</i>	<i>Pass-through</i>	72
73	GND	GND	74
75	<i>Pass-through</i>	<i>Pass-through</i>	76
77	<i>Pass-through</i>	<i>Pass-through</i>	78
79	GND	GND	80
81	SATA_1Tp ²	SATA_0Tp ²	82
83	SATA_1Tn ²	SATA_0Tn ²	84
85	GND	GND	86
87	<i>Pass-through</i>	<i>Pass-through</i>	88
89	<i>Pass-through</i>	<i>Pass-through</i>	90
91	GND	GND	92
93	<i>Pass-through</i>	<i>Pass-through</i>	94
95	<i>Pass-through</i>	<i>Pass-through</i>	96
97	GND	GND	98
99	SATA_DET#1 ²	SATA_DET#0 ²	100
101	SATA_PWREN#1 ²	SATA_PWREN#0 ²	102
103	GND	GND	104

+5 Volts

Table 2 PCIe/104 Type 2 Bus Signal Assignments¹

Pin	Signal	Signal	Pin
105	Pass-through	Pass-through	106
107	GND	GND	108
109	Pass-through	Pass-through	110
111	Pass-through	Pass-through	112
113	GND	GND	114
115	Pass-through	Pass-through	116
117	Pass-through	Pass-through	118
119	GND	GND	120
121	Pass-through	Pass-through	122
123	Pass-through	Pass-through	124
125	GND	GND	126
127	Pass-through	Pass-through	128
129	Pass-through	Pass-through	130
131	GND	GND	132
133	SATA_1Rp ²	SATA_0Rp ²	134
135	SATA_1Rn ²	SATA_0Rn ²	136
137	GND	GND	138
139	Pass-through	Pass-through	140
141	Pass-through	Pass-through	142
143	GND	GND	144
145	Pass-through	Pass-through	146
147	Pass-through	Pass-through	148
149	GND	GND	150
151	Pass-through	Pass-through	152
153	Pass-through	Pass-through	154
155	GND	GND	156

+12 Volts

1.Signals marked with (#) are active low.

2.For a description of SATA lane usage on the RSATA34106, refer to *SATA Link Shifting* — page 20.

2.5" SATA Drive Connector (CN3)

The 2.5" SATA drive connector on the RSATA34106 provides a convenient interface to the first SATA link on the PCIe/104 Type 2 bus on RTD's PCI Express cpuModules.

SATA Link Shifting

The RSATA34106's 2.5" SATA Drive Connector (**CN3**) utilizes the first SATA link on the PCIe/104 Type 2 bus. As a result, the unused SATA link on the bus is shifted from the bottom-side PCIe/104 Type 2 connector (**CN2**) to the top-side (**CN1**). Shifting the remaining link allows a second RSATA34106 (or other SATA drive carrier) to be installed upwards in the stack.

Figure 3 shows a block diagram of the SATA drive carrier module and how it interfaces to the cpuModule.





Figure 3 RSATA34106 - Block Diagram

Appendix 1 IDAN™ Dimensions and Pinout


SATA Drive Carrier modules, like all other RTD PC/PCI-104, PCI/104-Express, and PCIe/104 modules, can be packaged in Intelligent Data Acquisition Node (IDAN) frames, which are milled aluminum frames with integrated heat sinks and heat pipes for fanless operation. RTD modules installed in IDAN frames are called building blocks. IDAN building blocks maintain the simple but rugged PC/104 stacking concept. Each RTD module is mounted in its own IDAN frame and all I/O connections are brought to the walls of each frame using standard PC connectors. No connections are made from module to module internal to the system other than through the PC/104 and PC/104-Plus bus, enabling quick interchangeability and system expansion without hours of rewiring and board redesign.

The RSATA34106 SATA Drive Carrier can also be purchased as part of a custom-built RTD HiDAN™ or HiDANplus™ High Reliability Intelligent Data Acquisition Node. This appendix provides the dimensions and pinouts of the RSATA34106 installed in an IDAN frame. Contact RTD for more information on high reliability IDAN, HiDAN, and HiDANplus PC/PCI-104, PCI/104-Express, and PCIe/104 systems.



IDAN—Adhering to the PC/104 stacking concept, IDAN allows you to build a customized system with any combination of RTD modules.

IDAN Heat Pipes—Advanced heat pipe technology maximizes heat transfer to heat sink fins.



HiDANplus—Integrating the modularity of IDAN with the ruggedization of HiDAN, HiDANplus enables connectors on all system frames, with signals running between frames through a dedicated stack-through raceway.

IDAN-RSATA-SYS104

The IDAN-RSATA-SYS104 is a RSATA34106 SATA Drive Carrier packaged in an IDAN frame. It includes a removable drawer which acts as a carrier for a 2.5" SATA drive, and permits easy removal of data from a PCI/104-Express or PCIe/104 system.



Note Photographs not to scale.



Figure 4 IDAN-RSATA-SYS104, Drawer Open



Figure 5 IDAN-RSATA-SYS104, Drawer Closed

Removable Drawer

The removable drawer carrier allows a 2.5" SATA drive to be easily added or removed from the IDAN-RSATA-SYS104. To install or remove a 2.5" SATA drive from the drawer, ten screws must be removed from the carrier, as shown in Figure 6, below.




Figure 6 IDAN-RSATA-SYS104 Drawer (Carrier)

Dimensional Drawing




Figure 7 IDAN-RSATA-SYS104 Dimensions



Note Drawing in inches.

Note Drawing not to scale.



Appendix 2 Limited Warranty

RTD Embedded Technologies, Inc. warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from RTD Embedded Technologies, Inc. This warranty is limited to the original purchaser of product and is not transferable.

During the one year warranty period, RTD Embedded Technologies will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to RTD Embedded Technologies. All replaced parts and products become the property of RTD Embedded Technologies. Before returning any product for repair, customers are required to contact the factory for a Return Material Authorization number.

This limited warranty does not extend to any products which have been damaged as a result of accident, misuse, abuse (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by RTD Embedded Technologies, "acts of god" or other contingencies beyond the control of RTD Embedded Technologies), or as a result of service or modification by anyone other than RTD Embedded Technologies. Except as expressly set forth above, no other warranties are expressed or implied, including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose, and RTD Embedded Technologies expressly disclaims all warranties not stated herein. All implied warranties, including implied warranties for merchantability and fitness for a particular purpose, are limited to the duration of this warranty. In the event the product is not free from defects as warranted above, the purchaser's sole remedy shall be repair or replacement as provided above. Under no circumstances will RTD Embedded Technologies be liable to the purchaser or any user for any damages, including any incidental or consequential damages, expenses, lost profits, lost savings, or other damages arising out of the use or inability to use the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, and some states do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RTD Embedded Technologies, Inc.
103 Innovation Blvd.
State College PA 16803-0906
USA
Website: www.rtd.com

